

LEADER

LV 5838

AUDIO MONITOR

INSTRUCTION MANUAL

TABLE OF CONTENTS

GENERAL SAFETY SUMMARY	I
1. INTRODUCTION	1
1.1 Scope of Warranty	1
1.2 Operating Precautions	1
1.2.1 Maximum Allowable Input Voltage	1
1.2.2 Mechanical Shock.....	2
1.2.3 Electrostatic Damage.....	2
1.2.4 Warming Up.....	2
1.2.5 Backup Battery	2
1.3 Trademark Acknowledgments.....	2
1.4 Notations Used in This Manual	3
2. SPECIFICATIONS.....	4
2.1 General.....	4
2.2 Features.....	4
2.3 Specifications.....	6
2.3.1 SDI Video Signal Formats and Standards.....	6
2.3.2 Embedded Audio Playback Method	8
2.3.3 I/O Connectors.....	8
2.3.4 LCD	9
2.3.5 Control Connectors.....	9
2.3.6 Display Indication.....	10
2.3.7 Level Meter Display	10
2.3.8 Lissajous Display	11
2.3.9 Surround Display	11
2.3.10 Loudness Display	11
2.3.11 Audio Status Display.....	12
2.3.12 SDI Status Display.....	13
2.3.13 PHY Display.....	13
2.3.14 Various Features.....	14
2.3.15 General Specifications.....	15
2.3.16 AC adapter (SPU40-105).....	15
3. PANEL DESCRIPTION.....	16
3.1 Front Panel	16
3.2 Rear Panel.....	17
4. BEFORE YOU BEGIN MEASURING	19
4.1 Turning the Instrument On and Off	19
4.2 Signal I/O	19
4.2.1 External Audio Signal Input/Output.....	19
4.2.2 SDI Signal Input/Output.....	20

4.2.3	Time Code Input	20
4.2.4	External Reference Signal Input	21
4.2.5	Headphone Output	21
4.2.6	DVI-D Output	21
4.3	General Display Explanation.....	22
4.4	Panel Operation Basics	24
4.4.1	Displaying the Function Menu	24
4.4.2	Function Menu Operations	25
4.4.3	Tab Menu Operations	25
4.4.4	Selecting the Measurement Signal	26
4.4.5	Selecting the Display Mode	26
4.4.6	1-Screen Display and 2-Screen Display	27
4.4.7	Mapping Measurement Channels	27
4.4.8	Setting the Key Lock.....	28
4.4.9	Preset Settings	29
5.	SYSTEM SETTINGS	30
5.1	General Settings	30
5.2	Configuring the Ethernet and Remote Settings.....	32
5.3	Other Settings.....	33
5.4	Setting the SDI Format	34
5.5	Configuring the Dolby Settings (Option).....	35
5.6	Configuring the Meter Settings	36
5.7	Configuring Loudness Settings 1	37
5.8	Configuring Loudness Settings 2	39
5.9	Configuring Downmix Settings	40
5.10	Configuring Audio Error Detection Settings.....	41
5.11	Configuring SDI Error Detection Settings.....	43
5.12	Configuring Event Log Settings	43
5.13	Setting the Date and Time	44
5.14	Displaying System Information	44
5.15	Initialization	45
6.	METER DISPLAY	46
6.1	Meter Display Description	46
6.2	Configuring Meter Display Settings.....	47
7.	LISSAJOUS DISPLAY	49
7.1	Lissajous Display Description	49
7.2	Configuring the Lissajous Settings.....	50
8.	SURROUND DISPLAY	51
8.1	Surround Display Description	51
8.2	Configuring Surround Display Settings	52

9.	LOUDNESS DISPLAY	53
9.1	Loudness Display Description.....	53
9.2	Configuring the Loudness Display Settings	57
9.2.1	Front Panel	57
9.2.2	LOUDNESS SETUP	58
9.3	Loudness Measurement	60
9.3.1	Manual Measurement	60
9.3.2	Remote Measurement	60
9.3.3	Time Code Measurement	61
9.3.4	CM Measurement	64
9.3.5	File Measurement.....	65
9.3.6	Real Time Measurement.....	65
10.	STATUS DISPLAY	66
10.1	Audio Section Display	66
10.1.1	Audio Section Display Description	66
10.1.2	Configuring the Audio Section Display Settings	70
10.2	SDI Section Display	71
10.2.1	SDI Section Display Description	71
10.2.2	Configuring the SDI Section Display Settings	71
10.3	Event Log Display	72
10.3.1	Event Log Display Description	72
10.3.2	Configuring Event Log Display Settings.....	74
10.4	dBTP Log Display	75
10.4.1	dBTP Log Display Description	75
10.4.2	Configuring dBTP Log Display Settings.....	76
10.5	PHY Display.....	77
10.5.1	PHY Display Description.....	77
10.5.2	Configuring the PHY Display Settings	78
11.	REMOTE CONTROL.....	79
12.	ETHERNET CONTROL.....	81
12.1	TELNET	81
12.1.1	Procedure	81
12.1.2	How to Enter Commands.....	82
12.1.3	TELNET Commands.....	83
12.2	SNMP	87
12.2.1	SMI Definitions.....	87
12.2.2	Procedure	87
12.2.3	Standard MIB.....	89
12.2.4	Enterprise MIB.....	94
12.2.5	Extended TRAP (Variable Binding List)	105
12.3	Time Server Function.....	106
12.3.1	Procedure	106
12.3.2	Time Adjustment Value	107

- 13. REFERENCE MATERIAL..... 109
 - 13.1 Menu Tree..... 109
 - 13.1.1 Mode Menu..... 109
 - 13.1.2 System Menu..... 110
 - 13.1.3 Assign Menu..... 111
 - 13.2 Firmware Update History 112

GENERAL SAFETY SUMMARY

■ Read This before Using the Instrument

This instrument should only be used by persons with sufficient knowledge of electronics who thoroughly understand the contents of this manual.




This instrument is not designed or manufactured for households or ordinary consumers. If unqualified personnel are to use the instrument, be sure the instrument is handled under the supervision of qualified personnel (those who have electrical knowledge). This is to prevent the possibility of personal injury or damage to the instrument.

■ Note about Reading This Manual

The contents of this manual contain specialized terminology and may be difficult to understand. If you have any questions about the contents of this manual, please contact your local LEADER agent.

■ Symbols and Terms

The following symbols and terms are used in this instruction manual and on the instrument to indicate important warnings and notes.

<p><Symbol></p> 	<p>This symbol appears in this instruction manual and on the instrument to indicate an area where improper handling could result in personal injury, damage to the instrument, or malfunction of the instrument or devices connected to it.</p> <p>When you encounter this symbol on the instrument, be sure to refer to the information in this instruction manual that corresponds to the area that the symbol marks.</p>
<p><Term></p>  WARNING	<p>Ignoring the precautions that this term indicates could lead to death or serious injury.</p>
<p><Term></p>  CAUTION	<p>Ignoring the precautions that this term indicates could lead to personal injury or damage to the instrument.</p>

GENERAL SAFETY SUMMARY

Read the warnings and information below thoroughly to avoid death, personal injury, and damage and deterioration of the instrument.



■ Warnings Concerning the Case and Panels

Do not remove the instrument's case or panels for any reason. Touching the internal components of the instrument could lead to fire or electric shock.

Also, do not allow foreign materials, such as liquids, combustible matter, and metal, to enter the instrument. Turning the instrument on when such materials are inside it could lead to fire, electric shock, damage to the instrument, or some other accident.

■ Installation Environment

● Operating Temperature Range

Use this instrument in a 0 to 40 °C environment. Using the instrument with its vents blocked or in a high temperature environment could lead to fire.

Drastic changes in temperature, such as might be caused by moving the instrument between two rooms with different temperatures, can damage the instrument by causing condensation to form within it. If there is a possibility that the instrument has condensation within it, wait for approximately 30 minutes before turning on the power.

● Operating Humidity Range

Use this instrument in an environment whose relative humidity is 85 % or less where there is no threat of condensation forming.

Also, do not operate this instrument with wet hands. Doing so could lead to electric shock or fire.

● Do Not Operate in an Explosive Atmosphere

Using this instrument in an environment where flammable gasses, explosive gasses, or steam is emitted or stored could lead to an explosion or fire. Do not use the instrument in such an environment.

● Do Not Insert Foreign Materials

If foreign materials, such as metal, flammable objects, or liquid are allowed into the instrument (through the vents for example), fire, electric shock, damage to the instrument, or some other accident may result.

■ If You Notice Something Wrong during Operation

If you notice smoke, fire, a strange smell, or something else that is wrong with the instrument while you are operating it, stop operation immediately. Failing to do so could lead to fire. Turn OFF the power switch, and remove the power cord from the outlet. After making sure that fire has not spread anywhere, contact your local LEADER agent.

GENERAL SAFETY SUMMARY



- **Warnings Concerning the Power Source**

Do not use a power source with a voltage other than the rated power source voltage for the instrument. Doing so could lead to fire.

- **Warnings Concerning the Panel**

Sections of the panel are made out of glass. If the glass breaks, the broken glass may lead to injury. Do not apply a strong shock to the panel, cut it with sharp metal, or damage it in any similar manner.



- **Cautions Concerning the Input and Output Connectors**

To avoid damaging the instrument, only apply signals to the input connectors that conform to the specifications in this instruction manual. Do not short or apply external voltage to the output connectors.

Doing so could damage the instrument.

- **Cautions Concerning the AC Adapter**

Only use the specified type of AC adapter. Using a non-specified type of adapter could damage the instrument and lead to fire.

We recommend you replace the AC adapter at least once every five years.

- **If You Will Not Use the Instrument for an Extended Period of Time**

If you will not use the instrument for an extended period of time, remove the power plug from the outlet.

GENERAL SAFETY SUMMARY

■ Calibration and Repairs

This instrument has been carefully examined at the factory to ensure that its performance is in accordance with the standards. However, because of factors such as parts wearing out over time, the performance of the instrument may degrade. To ensure stable performance, we recommend that you have the instrument calibrated regularly. Also, if the instrument malfunctions, repairs are necessary. For repairs and calibration, contact your local LEADER agent.

■ Routine Maintenance

When you clean the instrument, remove the power plug from the outlet.

Do not use thinner or benzene when you clean the instrument's case, panels, or knobs. Doing so could lead to paint chipping and the corrosion of plastic components. To clean the case, panels, and knobs, use a soft cloth with mild detergent, and wipe gently. While cleaning, make sure that foreign materials, such as water and detergent, do not enter the instrument. If liquid or a metal object enters into the instrument, fire or electric shock may result.

■ About the European WEEE Directive



This instrument and its accessories are subject to the European WEEE Directive.

Follow the applicable regulations of your country or region when discarding this instrument or its accessories. Follow the EU Battery Directive when discarding the batteries that you removed from this instrument.

(WEEE stands for Waste Electrical and Electronic Equipment.)

Follow the warnings and precautions that have been listed in this section to use the instrument correctly and safely. Precautions are also contained in various other sections of this instruction manual. To use the instrument correctly, be sure to follow those precautions as well.

If you have any questions or comments about this instruction manual, please contact your local LEADER agent.

1. INTRODUCTION

Thank you for purchasing this LEADER instrument. To use this instrument safely, read this instruction manual thoroughly, and make sure that you know how to use the instrument properly.

If some point about the operation of this instrument is still unclear after you have read this instruction manual, refer to the contact information on the back cover of the manual to contact LEADER, or contact your local LEADER agent.

After you have finished reading this manual, keep it in a convenient place so that you can refer to it when necessary.

1.1 Scope of Warranty

This LEADER instrument has been manufactured under the strictest quality control guidelines.

LEADER shall not be obligated to furnish the following free services during the warranty period.

1. Repair of malfunction or damages resulting from fire, natural calamity, or improper voltage applied by the user.
2. Repair of an instrument that has been improperly repaired, adjusted, or modified by personnel other than a factory-trained LEADER representative.
3. Repair of malfunctions or damages resulting from improper use.
4. Repair of malfunctions caused by devices other than this instrument.
5. Repair of malfunctions or damages without the presentation of a proof of purchase or receipt bill for the instrument.

1.2 Operating Precautions

1.2.1 Maximum Allowable Input Voltage



The maximum signal voltage that can be applied to the input connectors is indicated below. Do not apply excessive voltage to the connectors. Doing so may damage the device or lead to injury.

Table 1-1 Maximum allowable input voltage

Input Connector	Maximum Allowable Input Voltage
DIGITAL AUDIO	±5 V (DC + peak AC)
SDI INPUT	±2 V (DC + peak AC)
EXT REF INPUT	±5 V (DC + peak AC)
REMOTE	+5 V

1. INTRODUCTION

1.2.2 Mechanical Shock

This instrument contains sensitive components, so it may be damaged if it is dropped or otherwise exposed to a strong shock.

1.2.3 Electrostatic Damage

Electronic components can be damaged by static discharge. Static electricity can build up in the core wire of a coaxial cable. Before connecting a coaxial cable to the instrument, short the core wire of the cable with the external conductor.

1.2.4 Warming Up

To ensure more accurate measurements, turn ON the instrument approximately 30 minutes before you intend to use it to allow its internal temperature to stabilize.

1.2.5 Backup Battery

This instrument has a last-memory feature. When you turn the power on, the instrument starts with the panel settings that were in use the last time that it was turned off. If the backup battery is out of power, the message "The last memory feature is disabled." will appear, and this last-memory feature will no longer work. In addition, the contents of all presets are deleted.

To continually use these features, we recommend that you replace the backup battery with a new one every five years after you purchase the instrument. You cannot replace the backup battery yourself. For more information, contact your nearest LEADER agent.

1.3 Trademark Acknowledgments

- The company and product names in this document are trademarks or registered trademarks of their respective holders.
- The MD5 algorithm, which is used by this instrument, was developed by RSA Security Inc. in the United States. This algorithm is available on a license-free and patent-free basis.

1.4 Notations Used in This Manual

This section explains the terminology used in this manual.

- **Measurement Screen**

Refers to a screen showing a meter, Lissajous curve, loudness, or status.

- **1-Screen Display**

Refers to the condition in which a measurement screen is shown on one screen.

You can switch between this display and 2-screen display using the SINGLE/MULTI key.

- **2-Screen Display**

Refers to the condition in which two measurement screens are shown top and bottom.

You can switch between this display and 1-screen display using the SINGLE/MULTI key.

- **External Audio Signals**

Refers to digital audio signals received through the DIGITAL AUDIO connector on the rear panel.

To measure these signals, press INPUT to select AES.

- **Embedded Audio Signals**

Refers to audio signals extracted from SDI signals received through the SDI connector on the rear panel.

To measure these signals, press INPUT to select SDI.

- **When Measuring AES**

Refers to the conditions in which AES is selected through the INPUT key.

- **When Measuring SDI**

Refers to the conditions in which SDI is selected through the INPUT key.

- **When Measuring Dolby (option)**

Refers to the condition in which, on the DOLBY tab in the system settings, Module is set to Dolby-E, Dolby-Digital, or Dolby-Digital-Plus.

- **Underlining**

In function menus and menu trees, the default settings are underlined.

2. SPECIFICATIONS

2.1 General

The LV 5838 is an audio monitor that can be used as an audio console or a master monitor. It supports external audio signals and audio signals embedded in 3G/HD/SD-SDI signals. On the basis of received signals, the LV 5838 can show a Lissajous display, surround display, audio status display, level meter display, or loudness measurement display, or a combination of these displays.

All errors and events can be logged with timestamps. Logs can be stored in external storage media.

2.2 Features

- **8 External Audio Signal I/O Connectors (16 channels)**

Equipped with 8 BNC connectors (16 channels) that can be switched between input and output. When the connectors are configured to function as inputs, the LV 5838 measures external audio signals received through these connectors.

When the connectors are configured to function as outputs, the LV 5838 can convert the audio signals embedded in SDI signals to AES/EBU signals and output them.

- **Headphone Output**

Equipped with a 3.5 mm mini headphone output jack.

- **Support for LPCM, Dolby E, Dolby Digital, and Dolby Digital Plus**

LPCM is supported as standard. Dolby E, Dolby Digital, and Dolby Digital Plus can be supported with a Dolby option.

- **Support for Audio Signals Embedded in SDI Signals**

Audio signals embedded in SDI signals can be extracted and measured.

- **Downmixed Signal Generation**

The LV 5838 can generate downmixed signals of 5.1-channel surround sound. Downmix coefficient and gain can be changed.

- **Level Meter Measurement Function**

The LV 5838 can display simultaneously level meters and peak hold meters for up to 16 channels. The level meter supports dBFS, Nordic, DIN, and BBC scales. For Nordic, DIN, and BBC scales, you can set test levels. The level meter for loudness measurements can display both absolute values and relative values in reference to a target level.

- **Lissajous Display**

The LV 5838 can display Lissajous curves and correlation meters of any two channels.

2. SPECIFICATIONS

- **Surround Display**

The LV 5838 supports surround display that shows sound field images based on L, R, C, Ls, and Rs channels. It can also simultaneously show Lissajous curves of adjacent channels and surround waveforms.

- **Status Display**

Transmission status and audio status of digital audio signals can be displayed for 16 channels simultaneously.

Meta data of Dolby E and Dolby Digital can also be analyzed and displayed.

- **Loudness Measurement**

Momentary, short-term, and integrated loudness measurements can be performed on any two signals from mono, stereo, 5.1 channel, and 5.1 channel downmix. The changes in the measured loudness values can also be displayed in chart form.

- **Event Log, Loudness Log, and dBTP Log**

Logs can be recorded with time codes and time server information.

- **Relative Frequency Measurement between External Reference Signals and Audio Signals**

Input audio signal frequency error can be measured relative to a tri-level signal, black burst signal, 10 MHz sinusoid signal, or 48 kHz word clock signal received through the EXT REF INPUT connector.

- **Amplitude Measurement of External Audio Signals**

Simplified amplitude measurement can be performed on external audio signals.

- **LTC Input**

The LTC input terminal can be used to manage logs in sync with time codes.

- **Switching Loudness Measurement On/Off through the Remote Connector**

Loudness measurement can be started, stopped, and cleared through the remote connector.

- **Frame Location Measurement**

Installation of the Dolby option enables the measurement of embedded header positions when the embedded audio signal is Non-PCM (Dolby E only).

- **Dolby Option**

Dolby E, Dolby Digital, and Dolby Digital Plus (*1) can be decoded and measured. Audio decoding can be performed on external audio signals and audio signals embedded in SDI signals.

*1 The LV 5838 supports up to 5.1 channel audio decoding.
Information such as metadata will not be displayed.

2. SPECIFICATIONS

2.3 Specifications

2.3.1 SDI Video Signal Formats and Standards

Bitrate	
3G-SDI	2.970 Gbps or 2.970/1.001 Gbps
HD-SDI	1.485 Gbps or 1.485/1.001 Gbps
SD-SDI	270 Mbps
Ancillary Data Standard	SMPTE ST 291
Format Setting	Auto setup (manual setup only for i/sF)
3G-SDI	Detects the format information within the payload ID (SMPTE ST 352) and automatically sets the format
HD-SDI, SD-SDI	Determines the format from the input signal's synchronization information and automatically sets the format.

Table 2-1 SD-SDI video signal formats and standards

Color System	Quantization	Scanning	Frame (Field) Rates	Corresponding Standard
YCbCr 4:2:2	10 bits	525i	59.94	SMPTE ST 259
		625i	50	

Table 2-2 HD-SDI video signal formats and standards

Color System	Quantization	Scanning	Frame (Field) Rates	Corresponding Standard
YCbCr 4:2:2	10 bits	1080i	60/59.94/50	SMPTE ST 274
		1080p	30/29.97/25/24/23.98	SMPTE ST 292
		1080PsF	30/29.97/25/24/23.98	
		720p	60/59.94/50/30/29.97/25/24/23.98	SMPTE ST 296 SMPTE ST 292

2. SPECIFICATIONS

Table 2-3 3G-SDI level A video signal formats and standards

Color System	Quantization	Scanning	Frame (Field) Rates	Corresponding Standard
YCbCr 4:2:2	10 bits	1080p	60/59.94/50	SMPTE ST 424
	12 bits	1080p	30/29.97/25/24/23.98	SMPTE ST 425
		1080PsF	30/29.97/25/24/23.98	
		1080i	60/59.94/50	
YCbCr 4:4:4	10 bits	1080p	30/29.97/25/24/23.98	
		1080PsF	30/29.97/25/24/23.98	
		1080i	60/59.94/50	
		720p	60/59.94/50/30/29.97/25/24/23.98	
	12 bits	1080p	30/29.97/25/24/23.98	
		1080PsF	30/29.97/25/24/23.98	
		1080i	60/59.94/50	
		RGB 4:4:4	10 bits	1080p
1080PsF	30/29.97/25/24/23.98			
1080i	60/59.94/50			
720p	60/59.94/50/30/29.97/25/24/23.98			
12 bits	1080p		30/29.97/25/24/23.98	
	1080PsF		30/29.97/25/24/23.98	
	1080i		60/59.94/50	
	1080p		24/23.98	(2048×1080)
	1080PsF	24/23.98		

Table 2-4 3G-SDI level B video signal formats and standards

Color System	Quantization	Scanning	Frame (Field) Rates	Corresponding Standard
YCbCr 4:2:2	10 bits	1080p	60/59.94/50	SMPTE ST 424
	12 bits	1080p	30/29.97/25/24/23.98	SMPTE ST 425
		1080PsF	30/29.97/25/24/23.98	
		1080i	60/59.94/50	
YCbCr 4:4:4	10 bits	1080p	30/29.97/25/24/23.98	
		1080PsF	30/29.97/25/24/23.98	
		1080i	60/59.94/50	
	12 bits	1080p	30/29.97/25/24/23.98	
		1080PsF	30/29.97/25/24/23.98	
		1080i	60/59.94/50	
RGB 4:4:4	10 bits	1080p	30/29.97/25/24/23.98	
		1080PsF	30/29.97/25/24/23.98	
		1080i	60/59.94/50	
	12 bits	1080p	30/29.97/25/24/23.98	
		1080PsF	30/29.97/25/24/23.98	
		1080i	60/59.94/50	
		1080p	24/23.98	(2048×1080)
		1080PsF	24/23.98	

2. SPECIFICATIONS

2.3.2 Embedded Audio Playback Method

Compliant Standards	
3G-SDI, HD-SDI	SMPTE ST 299
SD-SDI	SMPTE ST 272
Format	LPCM, Dolby E (option), Dolby Digital (option), and Dolby Digital Plus (option)
Quantization	24 bits
Clock Generation	Generated from the video clock
Synchronization	All audio signals must be synchronized to the video clock.

2.3.3 I/O Connectors

SDI Signal I/O Connectors

Input Connector	2 BNC connectors
Input Impedance	75 Ω
Input Return Loss	
5 M to 1.485 GHz	15 dB or more
1.485 to 2.97 GHz	10 dB or more
Maximum Input Voltage	± 2 V (DC + peak AC)

SDI Signal Output Connector

Output Connector	1 BNC connector
Output Signal	Transmits a serial reclocked signal of the signal received through the SDI signal input connector
Output Impedance	75 Ω
Output Return Loss	
5 M to 1.485 GHz	15 dB or more
1.485 G to 2.97 GHz	10 dB or more

Audio Signal Input/Output Connectors

I/O Connectors	8 BNC connectors, 16 channels
I/O Impedance	75 Ω
Supported Formats	LPCM, Dolby E (option), Dolby Digital (option), and Dolby Digital Plus (option)
Sampling Frequency	32 k to 192 kHz
Quantization	24 bits
Maximum Input Voltage	± 5 V (DC + peak AC)
Output Voltage	1.0 Vp-p \pm 10 % (into 75 Ω)

Headphone Jack

Output Connector	One 3.5 mm mini jack
Output Signal	Two channels out of all the input audio signals
Volume Adjustment	VOLUME knob
Output Voltage	100 mW maximum (into 8 Ω load resistance)

2. SPECIFICATIONS

Video Output Connector

Output Connector	One DVI-D connector
Output Signal	Digital signal of the LCD display
Resolution	VGA (640×480 dots)
Aspect Ratio	4:3
Signal Format	Single Link T.M.D.S
DDC	Not supported
Hot Plug Detection	Not supported

EXT REF INPUT Connector

Input Connector	1 BNC connector
Input Signal	Tri-level sync, NTSC/PAL black burst signal, 10 MHz sinusoid signal, or 48 kHz word clock signal
Input Impedance	Tri-level sync or NTSC/PAL black burst signal 75 Ω
10 MHz sinusoidal signal	75 Ω
48 kHz word-clock signal	75 Ω, 20 kΩ
Maximum Input Voltage	±5 V (DC + peak AC)

LTC INPUT Connector

Compliant Standards	SMPTE ST 12
Input Connector	1 BNC connector
Input Signal	LTC signal
Input Impedance	≤ 20 kΩ
Maximum Input Voltage	±5 V (DC + peak AC)

2.3.4 LCD

Type	6.3-inch color TFT
Resolution	VGA (640×480 dots)

2.3.5 Control Connectors

USB Port

Compliant Standard	USB 2.0
Supported Media	USB memory devices
Function	Event log and loudness log output

Ethernet Port

Compliant Standard	IEEE802.3
Supported Protocol	TELNET, SNMP
Port	RJ-45
Function	Used to monitor the LV 5838 from a PC and to monitor errors
Type	10Base-T/100Base-TX

2. SPECIFICATIONS

Remote Connector	
Connector	15-pin D-sub (female)
Locking Screws	Inch screws (No.4-40UNC)
Function	Used to recall presets, control loudness measurement, and output alarms
Control Signal	LVTTL level (low active)
Input Voltage Range	0 to 5 V
2.3.6	Display Indication
Function	Switch between the 1-screen and 2-screen displays
1-Screen Display	Displays a single, large screen
2-Screen Display	Displays two screens, top and bottom
2.3.7	Level Meter Display
Display Modes	Assign up to 16 audio channels to level meters
Audio Level Meter	
Numeric Display	Numeric display based on the specified scale
Response Model	True-Peak, PPM-Typel, PPM-Typell, VU
Reference Level Range	-40 to 0 dBFS (1 dBFS steps)
Warning Level Range	-40 to 0 dBFS (1 dBFS steps)
Color	
Reference Level or Less	Green
Between the Reference Level and Warning Level	Yellow
Warning Level or Higher	Red
Peak Hold Meter	
Response Model	True-Peak, PPM-Typel, PPM-Typell, OFF
Peak Hold Time	0.0 to 5.0 s; HOLD (0.5/1.0 s steps)
Meter Scale	
Compliant Standard	dBFS, Nordic, DIN, BBC (For Nordic, DIN, and BBC, measured values are converted in reference to a test level, and the results are displayed on the respective level meter.)
Dynamic Range	
dBFS	-60 to 0 dBFS
Nordic	-42 to 12 dB
DIN	-50 to 5 dB
BBC	1 to 7 dB
Dynamic Range Expansion	Reference \pm 5 dB is displayed expanded.

2. SPECIFICATIONS

2.3.8	Lissajous Display	
	Display Modes	Displays an audio Lissajous waveform of the two channels that you select
	Channel Mapping	Select 2 channels from among 16 channels
	AGC Setting	ON or OFF
	AGC Operating Range	-45 to 0 dBFS
	Correlation Meter	Displays the correlation coefficient between the pair of signals assigned to the Lissajous display using a value between -1 and 1
2.3.9	Surround Display	
	Display Modes	Displays a graphical representation of a sound field
	Surround Formats	Stereo, 5.1ch
	Channel Mapping	Assign channels to L, R, C, Ls, and Rs as you like
	Center Channel Format	Normal, phantom center
	AGC Setting	ON or OFF
	AGC Operating Range	-45 to 0 dBFS
2.3.10	Loudness Display	
	Measurement Mode	Mono, stereo, 5.1, downmix, custom
	Channel Mapping	Assign channels to L, R, C, LFE, Ls, and Rs as you like
	Level Meter Display Format	Momentary loudness, short-term loudness, integrated loudness
	Chart Display	Displays changes of momentary loudness, short-term loudness, and integrated loudness over time on a graph
	Display Time	1min, 4min, 10min, 30min, 1hour, 2hour, 4hour, 6hour, 12hour, 24hour (Only group 1 is measured when 24hour is specified)
	Dynamic Range	-70 to 0 (LKFS/LUFS)
	Dynamic Range Expansion	Expands the range -36 to 18 (LK/LU) or -18 to 9 (LK/LU) in reference to the reference level
	Operation mode	BS1770-2, ARIB, EBU, ATSC, CUSTOM
	CUSTOM Mode Settings	
	Target Level	-99 to 0 LKFS
	LFE Gain	0.0 to 10.0
	BlockSize	200 ms to 30 s
	OverlapSize	0 to 99%
	UpperThres	0 to 5
	LowerThres	-5 to 0
	Absolute Level	-99 to 0 LKFS
	Relative Level	-99 to 0 LKFS
	Control Method	START/PAUSE key, remote connector, time code, CM submission data reference trigger, real time

2. SPECIFICATIONS

2.3.11 Audio Status Display

Error Detection	
Level Over	Counted as an error when a value exceeding the specified level is received
Level Range	-40 to 0 dBFS
Clipping	Counted as an error when a maximum signal is received for longer than the specified duration
Duration Range	1 to 100 samples
Mute	Counted as an error when a value below the specified level is received for longer than the specified duration
Level Range	-99 to -60 dBFS
Duration Range	1 to 100 samples
Silence	Counted as an error when a mute signal is received for longer than the specified duration
Duration Range	1 to 5000 ms
Parity	Counted as an error when the parity bit of the external audio signal and the value calculated on the LV 5838 are different.
Validity	Displays the validity bit status of the external audio signal
CRC	Counted as an error when the CRC value of the external audio signal and the value calculated on the LV 5838 are different.
Dolby CRC (option)	Counted as an error when the CRC value of the Dolby E or Dolby Digital signal and the value calculated by the Dolby module are different
Frame Location (option)	Displays the embedded header position and mode when the embedded audio signal is Non-PCM (Dolby E only)
Elapsed Time	Displays the amount of time that has elapsed since an error was reset
Channel Status Bits	
Display Formats	Binary display, text display
Analysis Display Information	Format, AudioData, Emphasis, SignalLock, SampleFrequency, Reference, ChannelMode, Resolution, Alignment, Origin, Destination, TimeCode, CRC
User Bits	
Display Formats	Binary display

2. SPECIFICATIONS

Dolby E Metadata (option)	
Compliant Standard	
External Audio Signals	AES3id
SDI Signal	SMPTE ST 2020、RDD 6
Display Formats	Text display
Displayed Contents	Dolby-E CommonMetadataStatus, AC-3 MetadataStatus, AC-3 ExtendedBitstreamInfo

Dolby Digital Metadata (option)	
Compliant Standard	
External Audio Signals	AES3id
SDI Signal	SMPTE ST 2020、RDD 6
Display Formats	Text display
Displayed Contents	AC-3 MetadataStatus, AC-3 ExtendedBitstreamInfo

2.3.12 SDI Status Display

Signal Detection	Detects the presence of an SDI signal
Format Display	Displays the video signal input format
Error Count	Up to 999,999 for each error type
Count Period	1 field
Embedded Audio Channel Display	Displays the embedded audio channel numbers
Embedded Audio Ancillary Data Packet Error Detection	
BCH	Detects audio data packet transmission errors
Parity	Detects audio data packet parity errors
DBN	Detects audio data packet continuity errors
Embedded Position	Detects the presence of audio in lines where it should not be embedded
Sample Count	Detects audio sample count errors

2.3.13 PHY Display

Relative Frequency Measurement	
Function	Measures the audio signal frequency error relative to the reference signal (external reference signal or external audio signal)
Reference Signal	Tri-level sync, NTSC/PAL black burst signal, 10 MHz sinusoid signal, 48 kHz word clock signal, external audio signal
Simplified Amplitude Measurement	
Function	Measures the amplitude of the external audio signal
Measurement Range	0.2 to 6.0 V (DC + peak AC)
Accuracy	±50 mV (for a 1 V signal whose rise or fall time is 30 ns to 44 ns)

2. SPECIFICATIONS

Sampling Frequency Display	
PHY FREQ	Detects and displays the physical sampling frequency of input signals
STATUS FREQ	Displays sampling frequency information in channel status

2.3.14 Various Features

Measurement Signal Selection

Function	Switches between the audio signal embedded in SDI signals and the external audio signal
Selection Method	INPUT key on the panel or through the Ethernet port

Preset Settings

Presets	Stores panel settings (excluding power on/off, date/time, Ethernet, and remote settings)
Number of Presets	5
Preset Loading Method	From the panel or through the Ethernet port or remote connector

Logging Feature

Function	Records events, loudness, and dBTP measurements with timestamps
Logging Method	From the panel or through the Ethernet port or remote connector

Time Display

Time	Current time, time code
Current Time Display	Displays time based on the internal clock
Time Code	LTC (ATC), VITC(ATC) , D-VITC, AESEBU, LTC (EXT)

Alarm Output

Display Indication	Displays a warning when the fan stops
Remote Connector	Outputs a signal when an error occurs

2. SPECIFICATIONS

2.3.15 General Specifications

Environmental Conditions

Operating Temperature	0 to 40°C
Operating Humidity Range	85 %RH or less (no condensation)
Optimal Temperature	10 to 30°C
Operating Environment	Indoors
Elevation	Up to 2,000 m
Overvoltage Category	II
Pollution Degree	2

Power Requirements

Voltage	10 to 18 VDC
Power Consumption	30 W max.

Dimensions 215 (W) × 128 (H) × 88 (D) mm (excluding protrusions)

Weight 1.7 kg

Accessories	AC adapter (SPU40-105)	1
	Power cord	1
	Instruction manual	1
	15-pin D-sub connector	1
	15-pin D-sub connector cover	1

2.3.16 AC adapter (SPU40-105)

Input 100 to 240 VAC, 50/60 Hz, 1 A

Output 12 VDC, 3.33 A max.

Dimensions 52 (W) × 34.5 (H) × 118 (D) mm (excluding the power cord)

Weight 0.35 kg (excluding the power cord)

3. PANEL DESCRIPTION

3.1 Front Panel






Figure 3-1 Front panel

Table 3-1 Front panel description

No.	Name	Description	Reference
1	Handle	A handle for carrying the LV 5838.	-
2	INPUT	Press the key to switch the measurement signal (SDI or AES). When the measurement signal is SDI, hold the key down to switch the measurement channel (A or B).	4.4.4
3	SYSTEM	Press the key to configure the LV 5838. Hold the key down to enable and disable the key lock.	5
4	PRESET	Hold the key down to register the panel settings. Press the key to recall a panel setting preset.	4.4.9
5	Power switch	Press the key to turn the power on. Hold the key down to turn the power off.	4.1
6	Power LED	Lights when the power is on.	-
7	Function keys	Use these keys to operate the menus.	4.4.2
8	SINGLE/MULTI	Switches between the 1-screen and 2-screen displays.	4.4.6
9		Selects the top screen during 2-screen display.	4.4.6
10		Selects the bottom screen during 2-screen display.	4.4.6
11	MODE	Shows the measurement screen and measurement menu.	4.4.5
12	ASSIGN	Assigns measurement channels.	4.4.7

3. PANEL DESCRIPTION

No.	Name	Description	Reference
13	START/PAUSE	Starts and pauses loudness measurement.	9.2
14	USB STORE	Saves the loudness log to a USB memory device.	9.2
15	CLEAR	Hold the key down to clear loudness measurement.	9.2
16	F•D	A function dial for configuring various settings.	-
17	VOLUME	Adjusts the headphone output volume.	4.2.5
18	Headphone	Outputs the audio of the selected channel. Connect a headphone (mini plug).	4.2.5
19	USB	Saves event logs and loudness logs. Connect a USB memory device.	9.2 10.3.2
20	LCD	Displays various screens.	-

3.2 Rear Panel




Figure 3-2 Rear panel

3. PANEL DESCRIPTION

Table 3-2 Rear panel description

No.	Name	Description	Reference
1	Fan	Cooling fan.	-
2	Serial Label	The serial number is printed on this label.	-
3	DC power inlet	Connect the supplied AC adapter to this inlet.	4.1
4	LTC INPUT	Time code input connector.	4.2.3
5	EXT REF INPUT	External reference input connector. Apply a tri-level sync, NTSC/PAL black burst signal, 10 MHz sinusoid signal, or 48 kHz word clock signal.	4.2.4
6	DIGITAL AUDIO	External audio signal I/O connectors.	4.2.1
7	REMOTE	15-pin D-sub remote control connector. This can be used to execute actions such as loading presets.	11
8	ETHERNET	Ethernet port. TELNET, SNMP, and time server functions can be used through this port.	12
9	DVI-D OUTPUT	DVI-D output connector. Outputs the display screen.	4.2.6
10	OUTPUT	Reclocks and outputs the selected channel, either the SDI signal applied to INPUT A or B.	4.2.2
11	INPUT A INPUT B	SDI signal input connectors.	4.2.2

4. BEFORE YOU BEGIN MEASURING

4.1 Turning the Instrument On and Off

- **Connecting the AC Adapter**




Figure 4-1 DC INPUT

Connect the included AC adapter to DC INPUT on the rear panel.

When the LV 5838 is connected to the AC adapter, some power is consumed even if the power switch is turned off. If you do not intend to use the LV 5838 for an extended period of time, disconnect the AC adapter.

- **Turning the Power On**

To turn on the power, press the power switch. The power LED lights, and the instrument turns ON. When you turn ON the power, the LV 5838 starts up with the same panel settings that were set when it was last turned OFF.

- **Turning the Power Off**

To turn off the power, hold down the power switch. The power LED and the instrument turn OFF.

4.2 Signal I/O

4.2.1 External Audio Signal Input/Output




Figure 4-2 DIGITAL AUDIO

Apply external audio signals to the DIGITAL AUDIO connectors on the rear panel.

To measure external audio signals, press INPUT on the front panel to select AES.

4. BEFORE YOU BEGIN MEASURING

You can switch the DIGITAL AUDIO connectors between input and output on the GENERAL tab in the system settings. Before you apply signals, check that the function of the connectors has been set to input. Failing to do so could damage the instrument. Use output signals for monitoring purposes.

[Reference] GENERAL tab → See section 5.1, “General Settings.”

Table 4-1 External audio signal input/output

	System Settings		CH 1/2 to CH 7/8	CH 9/10 to CH 15/16
During SDI measurement	Ext AES at SDI-INPUT	Input	Input connector	Input connector
		Output	Output connector (*1)	Output connector (*1)
During AES measurement	Ext AES Ch9-16 at AES-INPUT	Input	Input connector	Input connector
		Output	Input connector	Output connector (*2)

*1 Outputs embedded audio signals.

*2 Outputs the signal received through CH 1/2 to CH 7/8.

4.2.2 SDI Signal Input/Output




Figure 4-3 SDI

Apply an SDI signal to INPUT A or INPUT B on the rear panel.

The input connectors are terminated internally at 75 Ω, so there is no need to connect terminators to them.

To measure embedded audio signals, press INPUT on the front panel to select SDI. You can switch measurement channels by holding down the INPUT key.

The OUTPUT connector transmits a reclocked signal of the selected channel, either the SDI signal applied to INPUT A or B. Use the signals for monitoring.

4.2.3 Time Code Input




Figure 4-4 LTC INPUT

Apply a time code signal to the LTC INPUT connector on the rear panel.

To use the input time code for measurements and logging, on the GENERAL tab in the system settings, set TIMECODE SETTING to LTC(EXT).

[Reference] GENERAL tab → See section 5.1, “General Settings.”

4.2.4 External Reference Signal Input




Figure 4-5 EXT REF INPUT

Apply a tri-level sync, NTSC/PAL black burst signal, 10 MHz sinusoid signal, or 48 kHz word clock signal to the EXT REF INPUT connector on the rear panel. This will be the reference signal for relative frequency measurements.

On the GENERAL tab in the system settings, specify EXT-REF INPUT FORMAT SETTING.

[Reference] Relative frequency measurements → See section 10.5, “PHY Display.”

GENERAL tab → See section 5.1, “PHY Display.”

4.2.5 Headphone Output

- **Selecting the Channels to Output**

Select the channels using PHONES on the assign menu. The selected channels are indicated in the upper right of the display.

[Reference] PHONES → See section 4.4.7, “Mapping Measurement Channels.”

- **Adjusting the Volume**

Use the VOLUME knob on the front panel to adjust the speaker output volume. Pressing the knob returns the volume to its normal setting.

The current volume is indicated in the upper right of the display.

Low volume	...	Normal volume	...	High volume

- **Connecting a Headphone**

Connect a headphone (mini plug) to the headphone jack on the front panel.

Check the volume before you put the headphones on.

4.2.6 DVI-D Output




Figure 4-6 DVI-D OUTPUT

The DVI-D output connector on the rear panel transmits the LV 5838 screen image. Using a DVI-D cable sold in the market, connect the LV 5838 to an VGA (640 × 480) display.

4.3 General Display Explanation

This section explains the common elements in all displays.




Figure 4-7 General display explanation

1 Date and time

Displays the date and time based on the TIME SETUP settings in the system settings or the date and time based on a time server. You can use Date and Time on the GENERAL tab to turn the display on and off.

- [Reference] TIME SETUP → See section 5.11, “Setting the Date and Time.”
- Time server → See section 12.3, “Time Server Function.”
- GENERAL tab → See section 5.1, “General Settings.”

2 Time code

Displays the time code when TIMECODE SETTING on the GENERAL tab in the system settings is not set to OFF.

- [Reference] GENERAL tab → See section 5.1, “General Settings.”

3 Measurement signal

Displays the measurement signal selected with the INPUT key as “AES,” “SDI A,” or “SDI B.”

- [Reference] INPUT key → See section 4.4.4, “Selecting the Measurement Signal.”

4 Format

During SDI measurement, the input signal format is indicated here. You can use Video Format on the GENERAL tab to turn the display on and off.

- [Reference] GENERAL tab → See section 5.1, “General Settings.”

5 Dolby indication (option)

Displays DOLBY-E when Module is set to Dolby-E, DOLBY-D when Module is set to Dolby-Digital, and DD+ when Module is set to Dolby-Digital-Plus on the DOLBY tab in the system settings. In addition, input groups and program configuration are displayed.
[Reference] DOLBY tab → See section 5.5, “Configuring the Dolby Settings (Option).”

6 Channel

Displays channels that are receiving input in white (other during Dolby measurement) and those that are not in gray.

7 MEAS, CALC, RMT, TC-P, TC, TCWP, TCW, CM-P, CM, FILE, RT-P, RT

Displays loudness measurement information.

[Reference] See section 9.3, “Loudness Measurement.”

MEAS: Appears when loudness measurement is in progress

CALC: Appears for a given period of time after loudness measurement is stopped

RMT: Appears when the remote measurement is in standby mode.

TC-P: Appears when the time code measurement is paused.

TC: Appears when the time code measurement is in standby mode.

TCWP: Appears when the overwriting of measured values is paused.

TCW: Appears when the overwriting of measured values is in standby mode.

CM-P: Appears when the CM measurement is paused.

CM: Appears when the CM measurement is in standby mode.

FILE: Appears when the file measurement is in standby mode.

RT-P: Appears when the real-time measurement is paused.

RT: Appears when the real-time measurement is in standby mode.

8 LOG

Appears when events are being logged. To turn event logging on and off, use LOG in the status menu.

[Reference] LOG → Section 10.3.2, “Configuring the Event Log”

9 AUDERR, SDIERR

Appears when an error occurs in one of the detection items that have been enabled on the AUDIO ERROR tab or SDI ERROR tab in the system settings.

Errors that are currently occurring and errors that have occurred in the past are distinguished as follows:

[Reference] AUDIO ERROR tab → See section 5.10, “Configuring Audio Error Detection Settings.”

SDI ERROR tab → See section 5.11, “Configuring SDI Error Detection Settings.”

10 Headphone

Displays the volume set with the VOLUME knob and the output channel set with PHONES L and PHONES R in the assign menu.

[Reference] See section 4.2.2, “Headphone Output.”

11 Key lock

Appears when the key lock is enabled. You can turn the key lock on and off by holding down the SYSTEM key.

[Reference] See section 4.4.8, "Setting the Key Lock."

12 USB

Appears when a USB memory device is connected to the USB port. This indicator is normally green, but it changes to red when the USB memory device is being accessed. Do not turn the power off or remove the USB memory device when the indicator is red.

13 Group (excluding the status)

Displays the display group selected under GROUP in the system settings as "GRP1," "GRP2," "ALL," "1-8," or "9-16."

[Reference] GROUP → See section 6.2, "Configuring the Meter Display, 7.2, "Configuring the Lissajous Display," 8.2, "Configuring the Surround Display," and 9.2, "Configuring the Loudness Display."

14 Audio mode (excluding the status)

Displays the audio mode selected under GROUP1 and GROUP2 in the assign menu as "MONO," "ST," "ALL," "5.1," "5.1DM," or "CUST." The audio mode is not displayed when GROUP in each mode menu is set to "ALL," "1-8," or "9-16."

[Reference] GROUP1, GROUP2 → See section 4.4.7, "Mapping Measurement Channels."

15 Loudness

Displays the integrated loudness value for each measurement group.

16 FAN ALARM

Appears when a fan error occurs. If this appears, turn off the LV 5838 immediately, and contact your local LEADER agent.

4.4 Panel Operation Basics

4.4.1 Displaying the Function Menu

• Displaying the System Menu

Press SYSTEM to display the system menu; press it again to clear it.

• Displaying the Assign Menu

Press ASSIGN to display the assign menu; press it again to clear it.

• Displaying the Mode Menu

Press MODE to display the mode menu; press it again to clear it.

The mode menu automatically disappears after 5 seconds of user inactivity. If this occurs, you can press a function key to display it again. You can change the length of time before the menu disappears on the ETC tab in the system settings.

[Reference] ETC tab → See section 5.3, "Other Settings."

4.4.2 Function Menu Operations




Figure 4-8 Assign menu

To select a setting from a list, as with **F•1** of the assign menu, press **F•1** repeatedly to select the setting you want. The setting changes each time you press **F•1**. After you stop pressing **F•1**, the setting is confirmed, and the pop-up menu disappears.

4.4.3 Tab Menu Operations

In the system settings and other settings, tab menus are used as shown below. This section explains how to operate the tab menu, using the METER 1 tab menu as an example.




Figure 4-9 METER 1 tab

- **Moving Cursors**

Turn the function dial (F•D) to move the cursor. Depending on what you are setting, there are some items in which you cannot move the cursor.

- **Switching Tabs**

When there are multiple tabs, such as in the figure above, press **F•2** PREV TAB and **F•3** NEXT TAB to change between tabs. Even if you switch to another tab, the settings are not confirmed until you press **F•1** COMPLETE.

- **Selecting Check Boxes**

Move the cursor to the check box that you want to select, and press the function dial (F•D).

4. BEFORE YOU BEGIN MEASURING

• Entering Values

Move the cursor to the item that you want to enter the value for, and press the function dial (F•D). When the cursor changes from light blue to yellow, turn the function dial (F•D) to set the value. After setting the value, press the function dial (F•D).

• Confirming Settings

Press **F•1** COMPLETE to apply the settings from all the tabs and return to the screen that is one level up.

• Canceling Settings

Press **F•7** UP MENU to cancel the settings from all the tabs and return to the screen that is one level up.

4.4.4 Selecting the Measurement Signal

External audio signals and embedded audio signals cannot be measured simultaneously. To switch the measurement signal, press the INPUT key on the front panel. During SDI measurement, hold down the INPUT key to switch the measurement channel. The signal that is currently being measured is displayed in the upper left of the screen as follows.



Figure 4-10 Selecting the measurement signal

4.4.5 Selecting the Display Mode

The measurement spring has several display modes. To switch the mode, press **F•1** DISPLAY on the mode menu. In 2-screen display mode, you can select the display mode of each screen separately.

Table 4-2 Selecting the display mode



Display Mode	Description	Reference
METER	Meters are displayed.	6
LISSAJOU	The Lissajous curves and meters are displayed.	7
SURROUND	Surround waveforms and meters are displayed.	8
LOUDNESS	Loudness meters and charts are displayed.	9
STATUS	Audio status, SDI status, event log, and PHY are displayed.	10

4. BEFORE YOU BEGIN MEASURING

4.4.6 1-Screen Display and 2-Screen Display

The LV 5838 can display one measurement screen (1-screen display) or two measurement screens top and bottom (2-screen display).

In 1-screen display, press SINGLE/MULTI to switch to 2-screen display.

In 2-screen display, press  to select the top screen,  to select the bottom screen, and SINGLE/MULTI to show the selected screen in 1-screen display.




Figure 4-11 1-screen display and 2-screen display

4.4.7 Mapping Measurement Channels

You can assign measurement channels on the assign menu.

The LV 5838 enables you to set up two audio groups and switch between them.




Figure 4-12 Assign menu

- **F-1** GROUP1: **MONO** / STEREO / 5.1 / 5.1_DM / CUSTOM
- **F-2** GROUP2: **OFF** / MONO / STEREO / 5.1 / 5.1_DM / CUSTOM

Select the audio mode of audio groups 1 and 2.

OFF: Audio group 2 is disabled.

MONO: The channel assigned to LRch is measured.

It is used to measure mono programs conforming to ARIB TR-B32.

STEREO: The channels assigned to L and Rch are measured.

5.1: The channels assigned to L, R, C, LFE, Ls, and Rsch are measured.

5.1_DM: The channels assigned to L, R, C, LFE, Ls, and Rsch as well as Lt and Rt are measured.

CUSTOM: The channels assigned to L, R, C, LFE, Ls, and Rsch are measured.

You can turn off certain channels.

- **F•3 CHANNEL SETTING**

Assign channels to audio groups 1 and 2. During Dolby measurement, this menu item is not displayed.

Channels set to Non Connect will not be measured.

	GROUP1 CHANNEL SETTING	GROUP2 CHANNEL SETTING
Lch	<input checked="" type="checkbox"/> CH1 <input type="checkbox"/> CH2 <input type="checkbox"/> CH3 <input type="checkbox"/> CH4 <input type="checkbox"/> CH5 <input type="checkbox"/> CH6 <input type="checkbox"/> CH7 <input type="checkbox"/> CH8 <input type="checkbox"/> CH9 <input type="checkbox"/> CH10 <input type="checkbox"/> CH11 <input type="checkbox"/> CH12 <input type="checkbox"/> CH13 <input type="checkbox"/> CH14 <input type="checkbox"/> CH15 <input type="checkbox"/> CH16 <input type="checkbox"/> Non Connect	
Rch	<input type="checkbox"/> CH1 <input checked="" type="checkbox"/> CH2 <input type="checkbox"/> CH3 <input type="checkbox"/> CH4 <input type="checkbox"/> CH5 <input type="checkbox"/> CH6 <input type="checkbox"/> CH7 <input type="checkbox"/> CH8 <input type="checkbox"/> CH9 <input type="checkbox"/> CH10 <input type="checkbox"/> CH11 <input type="checkbox"/> CH12 <input type="checkbox"/> CH13 <input type="checkbox"/> CH14 <input type="checkbox"/> CH15 <input type="checkbox"/> CH16 <input type="checkbox"/> Non Connect	
Cch	<input type="checkbox"/> CH1 <input type="checkbox"/> CH2 <input checked="" type="checkbox"/> CH3 <input type="checkbox"/> CH4 <input type="checkbox"/> CH5 <input type="checkbox"/> CH6 <input type="checkbox"/> CH7 <input type="checkbox"/> CH8 <input type="checkbox"/> CH9 <input type="checkbox"/> CH10 <input type="checkbox"/> CH11 <input type="checkbox"/> CH12 <input type="checkbox"/> CH13 <input type="checkbox"/> CH14 <input type="checkbox"/> CH15 <input type="checkbox"/> CH16 <input type="checkbox"/> Non Connect	
LFEch	<input type="checkbox"/> CH1 <input type="checkbox"/> CH2 <input type="checkbox"/> CH3 <input checked="" type="checkbox"/> CH4 <input type="checkbox"/> CH5 <input type="checkbox"/> CH6 <input type="checkbox"/> CH7 <input type="checkbox"/> CH8 <input type="checkbox"/> CH9 <input type="checkbox"/> CH10 <input type="checkbox"/> CH11 <input type="checkbox"/> CH12 <input type="checkbox"/> CH13 <input type="checkbox"/> CH14 <input type="checkbox"/> CH15 <input type="checkbox"/> CH16 <input type="checkbox"/> Non Connect	
Lsch	<input type="checkbox"/> CH1 <input type="checkbox"/> CH2 <input type="checkbox"/> CH3 <input type="checkbox"/> CH4 <input checked="" type="checkbox"/> CH5 <input type="checkbox"/> CH6 <input type="checkbox"/> CH7 <input type="checkbox"/> CH8 <input type="checkbox"/> CH9 <input type="checkbox"/> CH10 <input type="checkbox"/> CH11 <input type="checkbox"/> CH12 <input type="checkbox"/> CH13 <input type="checkbox"/> CH14 <input type="checkbox"/> CH15 <input type="checkbox"/> CH16 <input type="checkbox"/> Non Connect	
Rsch	<input type="checkbox"/> CH1 <input type="checkbox"/> CH2 <input type="checkbox"/> CH3 <input type="checkbox"/> CH4 <input type="checkbox"/> CH5 <input checked="" type="checkbox"/> CH6 <input type="checkbox"/> CH7 <input type="checkbox"/> CH8 <input type="checkbox"/> CH9 <input type="checkbox"/> CH10 <input type="checkbox"/> CH11 <input type="checkbox"/> CH12 <input type="checkbox"/> CH13 <input type="checkbox"/> CH14 <input type="checkbox"/> CH15 <input type="checkbox"/> CH16 <input type="checkbox"/> Non Connect	

Figure 4-13 GROUP1 CHANNEL SETTING tab

- **F•4 PHONES L: 1 - 16 / D1 - D8 / DAUX**

- **F•5 PHONES R: 1 - 2 - 16 / D1 - D8 / DAUX**

Assign the headphone output channels.

The selected channels are indicated in the upper right of the display.

- **F•6 AUX CH: LT/RT / LO/RO / MONO / MUTE**

- **F•7 AUX CH DRC: LINE / RF**

When **F•4** PHONES L or **F•5** PHONES R is set to DAUX, set the AUX channel.

4.4.8 Setting the Key Lock

You can prevent unintentional operations on the LV 5838 by enabling the key lock. The key lock disables all LV 5838 keys except for the power switch.

- **Enabling the Key Lock**

Hold down SYSTEM until the message “KEYLOCK” appears on the screen. While the key lock is enabled, a key symbol appears in the upper right of the screen.

- **Releasing the Key Lock**

Hold down SYSTEM until the message “KEYLOCK Canceled.” appears on the screen.

4.4.9 Preset Settings

You can register up to five panel setting presets. Registered presets are not initialized when you press **SYSTEM** and then **F•7** INITIALIZE.

- **Registering a Preset**

Hold down a PRESET key (1 to 5). When the message “Completion of data storage.” disappears, the registration is complete. If there is already a preset registered at the selected number, it will be overwritten.

The following items are not stored in preset settings.

- Ethernet and remote settings (ETHER&REMOTE tab)
- Backlight settings (ETC tab)
- Date and time settings (TIME tab)

- **Recalling a Preset**

Press a PRESET key (1 to 5). If there is no preset at the selected number, the message “No recall data.” will appear.

5. SYSTEM SETTINGS

You can configure general LV 5838 settings on the system menu.
To display the system menu, press SYSTEM.




Figure 5-1 System menu

5.1 General Settings

To configure general settings, use the GENERAL tab.




Figure 5-2 GENERAL tab

- **Date:** Y/M/D / M/D/Y / D/M/Y / OFF

Select the display format for the date that is shown in the upper left of the screen. Select off to hide the date.

- **Time:** ON / OFF

Turn the time display in the upper left of the screen on or off.

- **Video Format:** ON / OFF

Turn the format display in the upper part of the screen on or off.

- **Ext AES at SDI-INPUT:** Input / Output

Switch the DIGITAL AUDIO connectors between input and output for SDI measurement.

Input: The connectors are set to input.

Output: The connectors are set to output. Embedded audio signals, channels 1 to 16, will be transmitted.

5. SYSTEM SETTINGS

- **Ext AES Ch9-16 at AES-INPUT: Input / Output**

Switch the DIGITAL AUDIO connector CH 9/10 through CH 15/16 between input and output for AES measurement. CH 1/2 through CH 7/8 are fixed as input connectors.

Input: The connectors are set to input.

Output: The connectors are set to output. The signal received through CH 1/2 to CH 7/8 are transmitted.

- **TIMECODE SETTING: OFF / LTC(ATC) / VITC(ATC) / D_VITC / AESEBU / LTC(EXT)**

Select the display format for the time code that is shown in the upper left of the screen. This also applies to various types of log data.

- **SRC SOURCE SETTING: ON / OFF
Ch1/2 - Ch15/16 / Internal**

Turn the sampling frequency conversion on or off.

Normally, set this to ON, and select a reference signal. If you select Internal, the frequency generated by the LV 5838 is used. If the input signal sampling frequency is not 48 kHz, select Internal.

- **INPUT SIGNAL: Video Sync / CW / WordClock**

Select the format of the external reference signal.

- **CLOCK: 48kHz / 44.1kHz / 32kHz**

When INPUT SIGNAL is set to Video Sync or CW, select the clock frequency of the external reference signal.

- **TERMINATION: 75Ω / 20kΩ**

When INPUT SIGNAL is set to WordClock, select the input impedance of the external reference signal.

5.2 Configuring the Ethernet and Remote Settings

To configure the Ethernet and remote settings, use the ETHER&REMOTE tab. These settings are not initialized when you press **SYSTEM** and then **F•7** INITIALIZE. [Reference] See section 11, "REMOTE CONTROL" and section 12, "ETHERNET CONTROL."

SYSTEM → **F•1** SYSTEM SETUP → **F•3** NEXT TAB →

GENERAL	ETHER&REMOTE	ETC				
ETHERNET SETTING						
Ethernet	<input type="checkbox"/> DHCP <input checked="" type="checkbox"/> IP					
IP Address	<table border="1"><tr><td>192</td><td>168</td><td>0</td><td>1</td></tr></table>	192	168	0	1	MAC ADDRESS
192	168	0	1			
Subnet Mask	<table border="1"><tr><td>255</td><td>255</td><td>255</td><td>0</td></tr></table>	255	255	255	0	00:00:00:00:00:00
255	255	255	0			
Gateway	<table border="1"><tr><td>0</td><td>0</td><td>0</td><td>0</td></tr></table>	0	0	0	0	
0	0	0	0			
TIME SERVER SETTING						
Time Server	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF	Time Zone				
IP Address	<table border="1"><tr><td>0</td><td>0</td><td>0</td><td>0</td></tr></table>	0	0	0	0	+09:00
0	0	0	0			
SNMP SETTING						
SNMP	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF					
ACCESS	<input checked="" type="checkbox"/> RO <input type="checkbox"/> RW					
SNMP Trap	<input checked="" type="checkbox"/> OFF <input type="checkbox"/> ON					
REMOTE SETTING						
Alarm Polarity	<input checked="" type="checkbox"/> Positive <input type="checkbox"/> Negative					
Select	<input checked="" type="checkbox"/> Recall <input type="checkbox"/> Recall and 5838_02 <input type="checkbox"/> 5838_01+02					

Figure 5-3 ETHER&REMOTE tab

- **Ethernet: DHCP / IP**

Select how to set the IP address.

If you select IP, set the IP address, subnet mask, and gateway below.

If you select DHCP, these are set automatically.

This setting is enabled after you restart the LV 5838.

- **Time Server: ON / OFF**

Select whether to enable the time server function.

When set to ON, set to the IP address of the time server in IP Address and the appropriate clock adjustment value in Time Zone.

- **SNMP: ON / OFF**

Select whether to enable the SNMP function.

- **ACCESS: RO / RW**

Select the SNMP access mode.

RO enables you to only read the settings; RW enables you to read and write the settings.

- **SNMP Trap: OFF / ON**

Select whether to enable trap output.

- **Alarm Polarity: Positive / Negative**

Select the polarity of the alarm signal that is transmitted from the remote connector.

- **Select: Recall / Recall and 5838_02 / 5838_01+02**

Select the remote connector operation mode.

5.3 Other Settings

To configure other settings, use the ETC tab.




Figure 5-4 ETC tab

- **LCD BACKLIGHT: 0 - 7 - 15**

Set the backlight brightness. The larger the number, the darker the backlight.

When you change the value, the brightness changes for verification, but it will not be applied until you press [F•1] COMPLETE.

- **MENU Auto Off: 5 - 60 (sec)**

Set the time until the mode menu automatically turns off. You can set the time in units of 5 seconds.

- **LOUDNESS TIME LIMIT: 12H / 24H**

Set the duration of loudness measurements. If you select 24H, you will not be able to measure the loudness of audio group 2.

5.4 Setting the SDI Format

To set the SDI format, use the SDI FORMAT tab.




Figure 5-5 SDI FORMAT tab

- **i/PsF Select: Interlace / **Segmented Frame****

Select the display format that is shown at the top of the screen.

5.5 Configuring the Dolby Settings (Option)

To configure the Dolby settings, use the DOLBY tab.

The DOLBY tab appears when the Dolby option is installed.

SYSTEM → **F•2** BEHAVIOR SETUP → **F•3** NEXT TAB →

SDI FORMAT	DOLBY	METER 1	METER 2	METER 3	DOWNMIX	AUDIO ERROR	SDI ERROR	LOG
MODULE SETTING								
Module		<input checked="" type="checkbox"/> OFF <input type="checkbox"/> Dolby-E <input type="checkbox"/> Dolby-Digital <input type="checkbox"/> Dolby-Digital-Plus (Sound Only 5.1ch MAX)						
Input Group		<input checked="" type="checkbox"/> Ch1/2 <input type="checkbox"/> Ch3/4 <input type="checkbox"/> Ch5/6 <input type="checkbox"/> Ch7/8 <input type="checkbox"/> Ch9/10 <input type="checkbox"/> Ch11/12 <input type="checkbox"/> Ch13/14 <input type="checkbox"/> Ch15/16						
Dolby-E SETTING								
Dialnorm		<input checked="" type="checkbox"/> OFF <input type="checkbox"/> ON						
Pulldown		<input checked="" type="checkbox"/> OFF <input type="checkbox"/> ON						
Dolby-Digital SETTING								
Listening		<input checked="" type="checkbox"/> Full <input type="checkbox"/> EX <input type="checkbox"/> 3stereo <input type="checkbox"/> Phantom <input type="checkbox"/> Stereo <input type="checkbox"/> Mono						
Prologic		<input checked="" type="checkbox"/> OFF <input type="checkbox"/> ON						
DRC		<input checked="" type="checkbox"/> Bypass <input type="checkbox"/> Line <input type="checkbox"/> RF						

Figure 5-6 DOLBY tab

- **Module:** OFF / Dolby-E / Dolby-Digital / Dolby-Digital-Plus

Set the measurement signal. If you select OFF, Dolby signals will not be measured.

- **Input Group:** Ch1/2 / Ch3/4 / Ch5/6 / Ch7/8 / Ch9/10 / Ch11/12 / Ch13/14 / Ch15/16

If Module is not set to OFF, select the channel to decode.

- **Dialnorm:** OFF / ON

Turn the dialog normalization of Dolby E on or off.

- **Pulldown:** OFF / ON

Turn the Dolby E pull-down feature on or off.

- **Listening:** Full / EX / 3stereo / Phantom / Stereo / Mono

Select the Dolby Digital listening mode.

- **Prologic:** OFF / ON

Turn the Dolby Digital Pro Logic on or off.

- **DRC:** Bypass / Line / RF

Select the Dolby Digital DRC (Dynamic Range Control).

5.6 Configuring the Meter Settings

To configure the meter settings, use the METER 1 tab.

These settings apply to the meters shown in the meter display, Lissajous display, and surround display.




Figure 5-7 METER 1 tab

- **Warning Index: -40 - -18 - 0 (dBFS)**

Set the warning level. Meters are normally displayed in green, but they are displayed in red if this value is exceeded.

- **Reference Index: -40 - -20 - 0 (dBFS)**

Set the reference level. Meters are normally displayed in green, but they are displayed in yellow when levels are between the Reference Index and Warning Index.

- **SCALE SETTING: dBFS / Nordic / DIN / BBC**

Select the scale type.

[Reference] SCALE MAG → See section 6.2, “Configuring the Meter Display”

Table 5-1 Selecting the scale

		SCALE MAG	
		OFF	ON
SCALE SETTING	dBFS	-60 to 0 dBFS	Reference Index ± 5 dB
	Nordic	-42 to 12 dB	Reference Index ± 5 dB
	DIN	-50 to 5 dB	Reference Index ± 5 dB
	BBC	1 to 7 dB	Reference Index ± 1.25 dB

5.7 Configuring Loudness Settings 1

The METER 2 and METER 3 tabs are used to set the loudness. Here we explain the METER 2 tab.

The settings that you specify here apply to the loudness display.

SYSTEM → F•2 BEHAVIOR SETUP → F•3 NEXT TAB (×3) →




Figure 5-8 METER 2 tab

- **Measure Mode: BS1770-2 / ARIB / EBU / ATSC / CUSTOM**

Select the integrated loudness measurement mode. The settings of each mode are shown below. If you select CUSTOM, you can specify the values.

Table 5-2 Selecting the measurement mode

	Measure Mode				
	BS1770-2	ARIB	EBU	ATSC	CUSTOM
Target Level	-24 (LKFS)	-24 (LKFS)	-23 (LUFS)	-24 (LKFS)	-99 to 0 (LKFS)
LFE Gain	0.0	0.0	0.0	0.0	0.0 to 10.0
BlockSize (ms)	400	400	400	400	200 to 30000
OverlapSize (%)	75	75	75	0	0 to 99
UpperThres	0	1	1	2	0 to 5
LowerThres	0	-1	-1	-2	-5 to 0
AbsoluteGating	ON	ON	ON	OFF	ON / OFF
Absolute Level	-70 (LKFS)	-70 (LKFS)	-70 (LUFS)	-	-99 to 0 (LKFS)
RelativeGating	ON	ON	ON	OFF	ON / OFF
Relative Level	-10 (LKFS)	-10 (LKFS)	-10 (LUFS)	-	-99 to 0 (LKFS)

- **SHORTTERM LOUDNESS: 200 - 3000 - 30000(ms)**

If Measure Mode is set to CUSTOM, set the duration for calculating short-term loudness. For all other modes, the duration is fixed at 3000.

- **MOMENTARY LOUDNESS: 100 - 400 - 1000(ms)**

If Measure Mode is set to CUSTOM, set the duration for calculating momentary loudness. For all other modes, the duration is fixed at 400.

- **CHART SETTING**

Select which loudness to display on the chart. Measurement is performed even if the check box is not selected.

- **dBTP OVER MARK: ON / OFF**

Select whether to enable the detection of peak levels of each channel that exceed the threshold. When set to ON, appropriate marks are indicated on the chart, "OVER" indications are displayed and recorded in the dBTP log.

The threshold is the LevelOver value specified on the AUDIO ERROR tab.

This cannot be selected when LevelOver is set to OFF. This feature does not work when the audio mode is 5.1 DM.

- **RELATIVE GATING LAMP: ON / OFF**

Select whether to display "RELATIVE" when the input signal is applicable for relative gating.

5.8 Configuring Loudness Settings 2

The METER 2 and METER 3 tabs are used to set the loudness. Here we explain the METER 3 tab.

The settings that you specify here apply to the loudness display.

SYSTEM → F•2 BEHAVIOR SETUP → F•3 NEXT TAB (x4) →

SDI FORMAT	DOLBY	METER 1	METER 2	METER 3	DOWNMIX	AUDIO ERROR	SDI ERROR	LOG
LOUDNESS SETTING 2								
LOUDNESS AUTO MEASURE								
Trigger		<input checked="" type="checkbox"/> OFF	<input type="checkbox"/> Remote	<input type="checkbox"/> Timecode				
		<input type="checkbox"/> CM	<input type="checkbox"/> FILE	<input type="checkbox"/> RealTime				
Trigger Time		0	0	0	-	0	0	1
								StopTime 3 s

Figure 5-9 METER 3 tab

- **Trigger: OFF / Remote / Timecode / CM / FILE / RealTime**

Set the automatic loudness measurement.

[Reference] See section 9.3, "Loudness Measurement."

OFF: Automatic measurement is disabled. Use the START/PAUSE key to start and stop a measurement. Use the CLEAR key to clear a measurement.

Remote: Measurement start, stop, and clear are executed through the remote control connector. On the ETHER&REMOTE tab in the system settings, you must set Select to Recall and 5838_02 or 5838_01+02.

Timecode: Measurement start and stop are executed on the basis of the time codes embedded in the input signals. Enter a value for Trigger Time. You must set TIMECODE SETTING on the GENERAL tab in the system settings to some setting other than OFF.

CM: Measurement start, stop, and clear and storage to USB memory are executed through audio input. For StopTime, enter how long loudness measurement will continue after the audio (active) stops.

FILE: Measurement is performed every approximately 20 seconds. Measured values are stored to USB memory. Use the START/PAUSE key to start and stop a measurement. Use the CLEAR key to clear a measurement.

RealTime: Measurement start and stop are executed according to the times specified on the LV 5838. Enter a value for Trigger Time.

5.9 Configuring Downmix Settings

To configure the downmix settings, use the DOWNMIX tab.

These settings are valid when GROUP1 or GROUP2 is set to 5.1_DM on the assign menu.

SYSTEM → F•2 BEHAVIOR SETUP → F•2 PREV TAB (×4) →

SDI FORMAT	DOLBY	METER 1	METER 2	METER 3	DOWNMIX	AUDIO ERROR	SDI ERROR	LOG
DOWNMIX Coefficient								
<input checked="" type="checkbox"/> 1/√2 <input type="checkbox"/> 1/2 <input type="checkbox"/> 1/2√2 <input type="checkbox"/> 0								
DOWNMIX Gain <input type="text" value="0.0"/> dB								

Figure 5-10 DOWNMIX tab

- **DOWNMIX Coefficient:** 1/√2 / 1/2 / 1/2√2 / 0
Select the downmix coefficient.
- **DOWNMIX Gain:** -3.0 - 0.0 - 3.0 (dB)
Select the downmix gain.

5.10 Configuring Audio Error Detection Settings

To configure the audio error detection settings, use the AUDIO ERROR tab.

The error counts for the items that are enabled on this tab will be displayed on the audio section display. They are also logged on the event log display.

[Reference] See section 10.1, “Audio Section Display” and section 10.2, “Event Log Display.”

SYSTEM → **F•2** BEHAVIOR SETUP → **F•2** PREV TAB (×3) →

SDI FORMAT	DOLBY	METER 1	METER 2	METER 3	DOWNMIX	AUDIO ERROR	SDI ERROR	LOG
AUDIO ERROR ACQUISITION SETTING								
<input checked="" type="checkbox"/> CH1	<input checked="" type="checkbox"/> CH2	<input checked="" type="checkbox"/> CH3	<input checked="" type="checkbox"/> CH4	<input checked="" type="checkbox"/> CH5	<input checked="" type="checkbox"/> CH6	<input checked="" type="checkbox"/> CH7	<input checked="" type="checkbox"/> CH8	
<input checked="" type="checkbox"/> CH9	<input checked="" type="checkbox"/> CH10	<input checked="" type="checkbox"/> CH11	<input checked="" type="checkbox"/> CH12	<input checked="" type="checkbox"/> CH13	<input checked="" type="checkbox"/> CH14	<input checked="" type="checkbox"/> CH15	<input checked="" type="checkbox"/> CH16	
AUDIO ERROR SETTING								
LevelOver	<input checked="" type="checkbox"/> ON	<input type="checkbox"/> OFF						
Level	<input type="text" value="-1"/>	dBFS						
Clip	<input checked="" type="checkbox"/> ON	<input type="checkbox"/> OFF	METER INDICATION					
Duration	<input type="text" value="10"/>	sample	Clip	<input type="checkbox"/> ON	<input checked="" type="checkbox"/> OFF			
Mute	<input type="checkbox"/> ON	<input checked="" type="checkbox"/> OFF	Mute	<input type="checkbox"/> ON	<input checked="" type="checkbox"/> OFF			
Duration	<input type="text" value="10"/>	sample	Silence	<input type="checkbox"/> ON	<input checked="" type="checkbox"/> OFF			
Level	<input type="text" value="-60"/>	dBFS						
Silence	<input type="checkbox"/> ON	<input checked="" type="checkbox"/> OFF						
Duration	<input type="text" value="1000"/>	ms						
Parity	<input checked="" type="checkbox"/> ON	<input type="checkbox"/> OFF	Validity	<input checked="" type="checkbox"/> ON	<input type="checkbox"/> OFF			
CRC	<input checked="" type="checkbox"/> ON	<input type="checkbox"/> OFF	Dolby CRC	<input checked="" type="checkbox"/> ON	<input type="checkbox"/> OFF			

Figure 5-11 AUDIO ERROR tab

• AUDIO ERROR ACQUISITION SETTING

Select the channels for detecting errors.

• LevelOver: ON / OFF

Level: -40 - -1 - 0 (dBFS)

Turn the level-over error detection on or off.

If you select ON, enter the level. An error is detected when a signal exceeding the specified level is received.

• Clip: ON / OFF

Duration: 1 - 10 - 100 (sample)

Turn the clip error detection on or off.

If you select ON, enter the duration. An error is detected when a maximum signal is received for longer than the specified duration.

• Mute: ON / OFF

Duration: 1 - 10 - 100 (sample)

Level: -99 - -60 (dBFS)

Turn the mute error detection on or off.

If you select ON, enter the duration and level. An error is detected when a value below the specified level is received for longer than the specified duration.

- **Silence: ON / OFF**

Duration: 1 - 1000 - 5000 (ms)

Turn the silence error detection on or off.

If you select ON, enter the duration. An error is detected when a mute signal is received for longer than the specified duration.

- **METER INDICATION: ON / OFF**

Turn the error display on or off.

If you select ON, errors are displayed on the meter when a clip error, mute error, or silence error is detected.

- **Parity: ON / OFF**

Turn the parity error detection on or off.

An error is detected when the parity bit of the input signal and the value calculated on the LV 5838 are different.

- **Validity: ON / OFF**

Turn the validity error detection on or off.

An error is detected when the validity bit of the input signal is inactive.

- **CRC: ON / OFF**

Turn the CRC error detection on or off.

An error is detected when the CRC of the channel status bits of the input signal and the value calculated on the LV 5838 are different.

- **Dolby CRC: ON / OFF (option)**

Turn the Dolby CRC error detection on or off. This item appears during Dolby measurement. (This is invalid during Dolby Digital Plus measurement.)

An error is detected when the CRC value of the Dolby signal and the value calculated on the Dolby module are different.

5.11 Configuring SDI Error Detection Settings

To configure the SDI error detection settings, use the SDI ERROR tab.

The error counts for the items that are enabled on this tab will be displayed on the SDI section display. They are also logged on the event log display.

[Reference] See section 10.2, “SDI Section Display” and section 10.3, “Event Log Display.”




Figure 5-12 SDI ERROR tab

5.12 Configuring Event Log Settings

To configure the event log settings, use the LOG tab.




Figure 5-13 LOG tab

- **LOGMODE SETTING: OverWrite / Stop**

The event log can hold 1000 entries. Select whether to overwrite the log or stop logging when the 1001st error occurs.

5.13 Setting the Date and Time

To set the date and time, use the TIME tab.

Enter the date and time that are shown in the upper left of the screen.

SYSTEM → F•3 TIME SETUP →

TIME	
DATE & TIME SETTING	
Year	2012
Month	9
Day	21
Hour	13
Minute	54
Second	11

Figure 5-14 TIME tab

5.14 Displaying System Information

You can view system information on the INFORMATION tab.

You can check the software version and other information.

SYSTEM → F•6 SYSTEM INFO →

INFORMATION	
LV5838:AUDIO MONITOR	
BOARD: 6: 0.1: 0.2:	FIRMWARE: 1.1

Figure 5-15 INFORMATION tab

5.15 Initialization

There are two ways to initialize the LV 5838. One is configuration initialization, and the other is factory default initialization. For details on initialization, see section 13.1, “Menu Trees.”

Table 5-3 Initialized items

	Configuration Initialization	Factory Default
Ethernet and remote settings (ETHER&REMOTE tab)	No	Yes
Preset contents	No	Yes
Date and time settings (TIME tab)	No	No

Yes: Initialized; No: Not initialized

- **Configuration Initialization**

To perform configuration initialization, use **F•7** INITIALIZE in the system menu. Press **F•1** INIT YES.




Figure 5-16 INITIALIZE menu

- **Factory Default Initialization**

To perform factory default initialization, turn on the power while holding down the function dial (F•D) and VOLUME.

When the message “SRAM/FLASH INITIALIZE” appears, press **F•1** YES.

6. METER DISPLAY

To display meters, set **[F•1]** DISPLAY on the mode menu to METER.

6.1 Meter Display Description

The meter display shows the level meters of the channels assigned on the assign menu. Up to 16 channels of meters can be displayed.




Figure 6-1 Meter display

1 Channel name display

The channel name (L, R, C, LFE, Ls, Rs, etc.) is displayed. This is not displayed when 16 channels are displayed.

2 Level display

The current level is displayed.

3 Peak Display

The peak value is displayed when **[F•2]** PEAKHOLD is not set to OFF.

4 Error Level Display

The error level that you specified on the AUDIO ERROR tab in the system settings is displayed.

[Reference] AUDIO ERROR tab → See section 5.10, “Configuring Audio Error Detection Settings.”

5 Meter display

Meters are displayed using the index colors specified on the METER 1 tab in the system settings.

[Reference] METER 1 tab → See section 5.4, “Configuring the Meter Settings.”

6 Error display

Errors are displayed when a clip error, mute error, or silence error is detected. They are displayed when METER INDICATION on the AUDIO ERROR tab in the system settings is set to ON.

[Reference] AUDIO ERROR tab → See section 5.10, “Configuring Audio Error Detection Settings.”

7 Channel display

The channel (1 to 16) is displayed. “X” is displayed for channels whose CHANNEL SETTING on the assign menu has been set to Non Connect.

[Reference] CHANNEL SETTING → See section 4.4.7, “Mapping Measurement Channels.”

8 RESPONSE

The response model that you selected with **F•1** RESPONSE is displayed.

9 PEAKHOLD

The response model that you selected with **F•2** PEAKHOLD is displayed.

6.2 Configuring Meter Display Settings

To configure the meter display settings, use **F•2** METER SETUP on the mode menu and the METER 1 tab in the system settings. This section explains **F•2** METER SETUP. For details on the METER 1 tab, see section 5.4, “Configuring the Meter Settings.”



Figure 6-2 METER SETUP menu

• **F•1** RESPONSE: TRUEPEAK / PPM(I) / PPM(II) / VU

Select the meter response model. The selected response model is indicated in the lower right of the screen.

Table 6-1 Selecting the response model

		Attack Time	Return Time	Average Time
RESPONSE	TRUEPEAK	0 s	1.7 s	-
	PPM(I)	10 ms	1.7 s	-
	PPM(II)	10 ms	2.8 s	-
	VU	-	-	300 ms

• **F•2** PEAKHOLD: OFF / TRUEPEAK / PPM(I) / PPM(II)

Select the response model of the peak hold meter. The selected response model is indicated in the lower right of the screen.

- **F•3 PEAKHOLD TIME: 0.0 / 0.5 / 1.0 / 2.0 / 3.0 / 4.0 / 5.0 / HOLD**
If **F•2** PEAKHOLD is not set to OFF, select the peak value hold time in seconds.
- **F•4 PEAKHOLD RESET**
If **F•2** PEAKHOLD is not set to OFF, press this key to reset the peak value.
- **F•5 SCALE MAG: OFF / ON**
Turn the expanded scale display on or off.
[Reference] SCALE SETTING, Reference Index → See section 5.4, "Configuring the Meter Display"

Figure 6-2 Turning the expanded display on and off

		SCALE MAG	
		OFF	ON
SCALE SETTING	dBFS	-60 to 0 dBFS	Reference Index ± 5 dB
	Nordic	-42 to 12 dB	Reference Index ± 5 dB
	DIN	-50 to 5 dB	Reference Index ± 5 dB
	BBC	1 to 7 dB	Reference Index ± 1.25 dB

- **F•6 GROUP: GROUP1 / GROUP2 / ALL / 1-8 / 9-16**
Select the display channels.
[Reference] GROUP1, GROUP2 → See section 4.4.7, "Mapping Measurement Channels."
- GROUP1: Channels that were selected using GROUP1 on the assign menu are displayed.
- GROUP2: Channels that were selected using GROUP2 on the assign menu are displayed.
This cannot be selected when GROUP2 is OFF.
- ALL: All channels are displayed.
- 1-8: Channels 1 to 8 are displayed. This cannot be selected during Dolby measurement.
- 9-16: Channels 9 to 16 are displayed. This cannot be selected during Dolby measurement.

7. LISSAJOUS DISPLAY

To display Lissajous curves, set **F•1** DISPLAY on the mode menu to LISSAJOU.

7.1 Lissajous Display Description

In the meter display, a Lissajous curve is displayed on the left half of the screen, and level meters are displayed on the right half of the screen. Lissajous waveform channels are assigned using **F•2** LCH and **F•3** RCH. Meter channels are assigned on the assign menu.




Figure 7-1 Lissajous display

1 L

The channel assigned using **F•2** LCH is displayed.

2 R

The channel assigned using **F•3** RCH is displayed.

3 Correlation meter

The correlation meter indicates the phase difference between the two signals. A reading of +1 indicates that the signals are in-phase, a reading of -1 indicates that the signals are 180 ° out of phase, and a reading of 0 indicates that the signals are not correlated.

4 Meter display

Level meters are displayed. See section 6.1, “Meter Display Description.”

7.2 Configuring the Lissajous Settings

To configure the Lissajous display settings, press **F•2** LISSAJOU SETUP in the mode menu.




Figure 7-2 LISSAJOU SETUP menu

- **F•2** LCH: CH 1 - CH 16 / D1 - D8 / Lt

- **F•3** RCH: CH 1 - CH 16 / D1 - D8 / Rt

Select the channels to assign to Lch and Rch of the Lissajous display. The channels that you can select varies depending on the **F•6** GROUP setting.

- **F•4** METER SETUP

Configure the meter settings. For a description of the settings, see section 6.2, “Configuring the Meter Display Settings.” However, **F•6** GROUP is not displayed.

- **F•5** AUTOGAIN: ON / OFF

Turn the AGC on or off. When set to ON, the gain is automatically adjusted so that the Lissajous curves fit within the scale. This is valid when the input signal is in the range of -45 to 0 dBFS.

- **F•6** GROUP: GROUP1 / GROUP2 / ALL / 1-8 / 9-16

Select the display channels.

[Reference] GROUP1, GROUP2 → See section 4.4.7, “Mapping Measurement Channels.”

GROUP1: In the meter display, channels that were selected using GROUP1 on the assign menu are displayed. In the Lissajous display, two channels that you select from this group are displayed.

GROUP2: In the meter display, channels that were selected using GROUP2 on the assign menu are displayed. In the Lissajous display, two channels that you select from this group are displayed.

This cannot be selected when GROUP2 is OFF.

ALL: In the meter display, all channels are displayed. In the Lissajous display, two channels that you select from all channels are displayed.

1-8: In the meter display, channels 1 to 8 are displayed. In the Lissajous display, two channels that you select from all channels are displayed. This cannot be selected during Dolby measurement.

9-16: In the meter display, channels 9 to 16 are displayed. In the Lissajous display, two channels that you select from all channels are displayed. This cannot be selected during Dolby measurement.

8. SURROUND DISPLAY

To show the surround display, set **F•1** DISPLAY on the mode menu to SURROUND.

8.1 Surround Display Description

In the surround display, a surround waveform is displayed on the left half of the screen, and level meters are displayed on the right half of the screen. Channels are assigned on the assign menu.




Figure 8-1 Surround display

1 Surround display

A surround waveform and Lissajous curves of adjacent channels are displayed. You can also display only one of the displays.

2 Meter display

The level meters of the channels assigned on the assign menu are displayed. See section 6.1, “ Meter Display Description.”

8.2 Configuring Surround Display Settings

To configure the surround display settings, press **F•2** SURROUND SETUP on the mode menu.




Figure 8-2 SURROUND SETUP menu

- F•1** **DISPLAY: BOTH / LISSAJOU / SURROUND**

Select whether to display both the surround waveform and Lissajous curves of adjacent channels or only one of two.
- F•2** **SURROUND MODE: NORMAL / PHANTOM**

Select the surround display format.

NORMAL: A waveform that combines Lch, Rch, Lsch, Rsch, and Cch (hard center) is displayed.

PHANTOM: A waveform that combines Lch, Rch, Lsch, Rsch, and phantom center and a Cch (hard center) waveform are displayed separately.
- F•4** **METER SETUP**

Configure the meter settings. For a description of the settings, see section 6.2, “Configuring the Meter Display Settings.” However, **F•6** GROUP is not displayed.
- F•5** **AUTOGAIN: ON / OFF**

Turn the AGC on or off. When set to ON, the gain is automatically adjusted so that the surround waveform fit within the scale. This is valid when the input signal is in the range of -45 to 0 dBFS.
- F•6** **GROUP: GROUP1 / GROUP2**

Select the display channels.

[Reference] GROUP1, GROUP2 → See section 4.4.7, “Mapping Measurement Channels.”

GROUP1: Channels that were selected using GROUP1 on the assign menu are displayed.

GROUP2: Channels that were selected using GROUP2 on the assign menu are displayed.

This cannot be selected when GROUP2 is OFF.

9. LOUDNESS DISPLAY

To show the loudness display, set **[F•1]** DISPLAY on the mode menu to LOUDNESS.

9.1 Loudness Display Description

In the loudness display, you can press **[F•1]** DISPLAY to switch the display format between chart, bar graph, numeric, and meter. Channels are assigned on the assign menu.

[F•1] DISPLAY = CHART




Figure 9-1 Chart display

[F•1] DISPLAY = BAR




Figure 9-2 Bar graph display

9. LOUDNESS DISPLAY

F•1 DISPLAY = NUM




Figure 9-3 Numeric display

F•1 DISPLAY = NUM ONLY




Figure 9-4 Numeric-only display




Figure 9-5 Meter display

1 Peak level display

The peak level of each channel is displayed.

2 Measurement time display

Loudness can be recorded up to 12 hours (this can be set to 24). The orange bar indicates the approximate measurement time. The green bar indicates the current display position. When you use the function dial (F•D) to move the display range, the green bar also moves.

[Reference] See section 5.3, “Other Settings.”

3 Chart display

The change in the loudness values over time is plotted on a chart. In addition, the measurement time codes are displayed next to the time values.

Loudness can be recorded up to 12 hours (this can be set to 24). Turn the function dial (F•D) to the right to view past loudness measurements. Press the function dial (F•D) to return to the current loudness measurement.

If dBTP OVER MARK is set to ON on the METER 3 tab in the system settings, when the peak level of a channel exceeds the “dBTP display” level, a red ▼ is displayed. The mark is not displayed if LevelOver is set to OFF on the AUDIO ERROR tab in the system settings or if the audio mode is set to 5.1 DM.

[Reference] METER 3 tab → See section 5.8, “Configuring Loudness Settings 2.”

AUDIO ERROR tab → See section 5.10, “Configuring Audio Error Detection Settings.”

4 dBTP

If dBTP OVER MARK is set to ON on the METER 3 tab in the system settings, the LevelOver value specified on the AUDIO ERROR tab is displayed.

[Reference] AUDIO ERROR tab → See section 5.10, “Configuring Audio Error Detection Settings.”

5 RELATIVE

This indication appears when the input signal is applicable for relative gating. This is displayed when RELATIVE GATING LAMP is set to ON on the METER 3 tab in the system settings.

6 OVER

This indication is displayed, if dBTP OVER MARK is set to ON on the METER 3 tab in the system settings, when the peak level of a channel exceeds the “dBTP display” level.

7 M

The momentary loudness is displayed.

The top value is an absolute value. The bottom value is a relative value with the target level as the reference (absolute value only for numeric-only display; relative value only for meter display.)

8 S

The short-term loudness is displayed.

The top value is an absolute value. The bottom value is a relative value with the target level as the reference (absolute value only for numeric-only display; relative value only for meter display.)

9 I

The integrated loudness is displayed.

The top value is an absolute value. The bottom value is a relative value with the target level as the reference (absolute value only for numeric-only display.)

The values are displayed in white during measurement but change to different colors depending on the loudness value calculated at the end of the measurement.

When the measurement mode is ARIB, the values are displayed as follows:

- $-23.0 < \text{measured value (LKFS)}$:Red
- $-25.0 \leq \text{measured value (LKFS)} \leq -23.0$:White
- $-28.0 \leq \text{measured value (LKFS)} \leq -25.1$:Yellow
- $\text{measured value (LKFS)} < -28.0$:Red

When the measurement mode is EBU, the values are displayed in red when they exceed the target level ± 1 (LU). Otherwise, they are displayed in white.

When the measurement mode is ATSC, the values are displayed in red when they exceed the target level ± 2 (LK). Otherwise, they are displayed in white.

10 Bar graph display

Loudness values are displayed on a bar graph.

Values are normally displayed in green, but they are displayed in yellow when they exceed the target level.

11 Meter display

The momentary loudness is displayed with a black needle, and the short-term loudness is displayed with a red needle. The target level is 0 (LK/LU) on the scale.

9.2 Configuring the Loudness Display Settings

To configure the loudness display settings, use LOUDNESS on the front panel, **F•2** LOUDNESS SETUP on the mode menu and the ETC (LOUDNESS TIME LIMIT), METER 2, METER 3, and AUDIO ERROR (LevelOver) tabs in the system settings. This section explains LOUDNESS on the front panel and **F•2** METER SETUP. For other details, see chapter 5, “SYSTEM SETTINGS.”

9.2.1 Front Panel



Figure 9-6 Front panel

- **START/PAUSE**

Press this key to start and pause loudness measurement. **MEAS** is displayed in the upper right of the screen when measurement is in progress. This key is valid regardless of the display mode.

- **USB STORE**

Press this key to store a loudness log to a USB memory device in CSV and text formats. This key is valid regardless of the display mode. Loudness logs are stored in the following location.

- └ USB memory device

- └ LV5838_USER

- └ LOUD

- └ yyyymmddhhmmss.csv; Time codes, loudness values, dBTPQVR (0 for normal, 1 for over)

- └ yyyymmddhhmmss.txt; Loudness settings, peak levels, loudness values, check results

- **CLEAR**

Hold this key down to clear the integrated loudness, chart display, and peak level display. This key is valid regardless of the display mode.

9.2.2 LOUDNESS SETUP




Figure 9-7 LOUDNESS SETUP menu

- **F•1** DISPLAY: CHART / BAR / NUM / NUM ONLY / METER

Select the display format of loudness values.

CHART: Values are plotted on a chart.

BAR: Values are displayed on a bar graph and a chart. The chart can be hidden.

NUM: Values are displayed numerically and on a chart. The chart can be hidden.

NUM ONLY: Values are displayed numerically.

METER: Values are displayed numerically and on meters and a chart. The chart can be hidden.

The meter displays the momentary loudness with a black needle and the short-term loudness with a red needle.

- **F•2** CHART SCALE: OFF / 1min / 4min / 10min / 30min / 1hour / 2hour / 4hour / 6hour / 12hour / 24hour

When **F•1** DISPLAY is not set to NUM ONLY, select the display time (horizontal axis) of the chart display. Select OFF to hide the chart.

24hour can be selected when on the ETC tab in the system settings, LOUDNESS TIME LIMIT is set to 24H.

[Reference] ETC tab → See section 5.3, “Other Settings.”

- **F•2** LOUDNESS SELECT: INTEGRATED / MOMENTARY / SHORTTERM / ALL

When **F•1** DISPLAY is set to NUM ONLY, select the display format of the loudness display.

INTEGRATED: The integrated loudness is displayed.

MOMENTARY: The momentary loudness is displayed.

SHORTTERM: The short-term loudness is displayed.

ALL: The integrated loudness, momentary loudness, and short-term loudness are displayed.

- **F•3** STYLE: VERT / HORI

When **F•1** DISPLAY is set to BAR, select the display format of the loudness display.

VERT: Bar graph (displayed vertically) and the chart are displayed side by side.

HORI: Bar graph (displayed horizontally) and the chart are displayed top and bottom.

- **F•4** INSERT SETTING

This appears after the end of a time code measurement. Use this setting to specify how to overwrite a portion of the loudness measurement results with other data.

[Reference] See section 9.3.3, “Time Code Measurement.”

- **F•5 SCALE MAG: OFF / WIDE / NARROW**

When **F•1** DISPLAY is set to CHART, BAR, or METER, select the scale range.

OFF: The range of -70 to 0 (LKFS/LUFS) is displayed.

You cannot select this when **F•1** DISPLAY is set to METER.

WIDE: The range of -36 to 18 (LK/LU) is displayed in reference to the target level.

NARROW: The range of -18 to 9 (LK/LU) is displayed in reference to the target level.

- **F•6 GROUP: GROUP1 / GROUP2**

Select the display channels. Only one group is displayed, but loudness measurements are performed on both groups simultaneously.

[Reference] GROUP1, GROUP2 → See section 4.4.7, "Mapping Measurement Channels."

GROUP1: Channels that were selected using GROUP1 on the assign menu are displayed.

GROUP2: Channels that were selected using GROUP2 on the assign menu are displayed.

This cannot be selected when GROUP2 is OFF.

9.3 Loudness Measurement

On the METER 2 tab in the system settings, the loudness measurement mode can be set to one of the following six settings: OFF, Remote, Timecode, CM, FILE, and RealTime. This section explains each mode.

[Reference] METER 2 tab → See section 5.7, “Configuring Loudness Settings 1.”

9.3.1 Manual Measurement

In manual measurement, a measurement is started, stopped, and cleared from the front panel. See section 9.2.1, “Front Panel.”

9.3.2 Remote Measurement

In remote measurement, a measurement is started, stopped, and cleared through the remote connector. To perform a measurement, follow the procedure below.

- 1. On the ETHER&REMOTE tab in the system settings, set Select to Recall and 5838_02 or 5838_01+02.**

[Reference] ETHER&REMOTE tab → See section 5.2, “Configuring the Ethernet and Remote Settings.”

- 2. On the METER 2 tab in the system settings, set Trigger to Remote.**

In the upper right of the display, **RMT** appears.

[Reference] METER 2 tab → See section 5.7, “Configuring Loudness Settings 1.”

- 3. Use pin 2 of the remote connector to start and stop a measurement and pin 4 to clear a measurement.**

The indicator in the upper right of the display changes to **MEAS** during measurement and returns to **RMT** when measurement ends.

During remote measurement, the START/PAUSE and CLEAR keys on the front panel are disabled.

9.3.3 Time Code Measurement

In time code measurement, measurement start and stop are executed on the basis of the time codes embedded in the input signals. To perform a measurement, follow the procedure below.

- 1. On the GENERAL tab in the system settings, set TIMECODE SETTING to some setting other than OFF.**

[Reference] GENERAL tab → See section 5.1, “General Settings.”

- 2. On the METER 2 tab in the system settings, set Trigger to Timecode, and enter the time code in Trigger Time.**

In the top section of the display, “PUSH ‘START’” appears. In the upper right, TC-P appears.

In this condition, measurement will not start even when the specified time code is reached.


[Reference] METER 2 tab → See section 5.7, “Configuring Loudness Settings 1.”

- 3. Press START/PAUSE.**

In the upper right of the display, TC appears. When the specified time code is reached, measurement starts or stops automatically. The indicator in the upper right of the display changes to MEAS during measurement and returns to TC when measurement ends.

• **Overwrite Mode**

When a time code measurement is complete, F•4 INSERT SETTING appears on the LOUDNESS SETUP menu. This feature automatically recalculates the total integrated loudness when a portion of the measured data is overwritten.



To overwrite data, follow the procedure below.

1. On the LOUDNESS SETUP menu, press F•4 INSERT SETTING.

The INSERT SETTING tab appears.




Figure 9-8 INSERT SETTING tab

2. Configure the overwrite settings.

- Insert Mode: Select to turn the overwrite mode on or off.
- Insert Select: Select whether to use a time code or the keys (manual) to specify the portion of the data to overwrite.
- Insert Trigger Time: If Insert Select is set to Timecode, enter the time codes that define the range to overwrite.

If you set Insert Mode to ON, TCWP appears in the upper right of the display. In this condition, measurement will not start even when the specified time code is reached.

3. Depending on the Insert Select setting, perform the following procedure.

Timecode


Press START/PAUSE, and then apply the audio signal. In the upper right of the display, TCW appears. When the specified time code is reached, measurement starts or stops automatically. The indicator in the upper right of the display changes to MEAS during overwriting and returns to TCWP when overwriting ends.

KEY

Apply the audio signal first, and press START/PAUSE when you want to start and stop overwriting. The indicator in the upper right of the display changes to MEAS during overwriting and returns to TCWP when overwriting ends.

• **Flowchart**

The following flowchart shows the procedure for overwriting a portion of the data in overwrite mode after a time code measurement.



9.3.4 CM Measurement

In CM measurement, measurement start, stop, clear, and storage to a USB memory device are executed through audio input triggers. To perform a measurement, follow the procedure below.

- 1. On the METER 2 tab in the system settings, set Trigger to CM. In StopTime, enter how long loudness measurement will continue after the audio (active) stops.**

In the top section of the display, "PUSH 'START'" appears. In the upper right, **CM-P** appears.

In this condition, measurement will not start even when an audio signal is applied.


[Reference] METER 2 tab → See section 5.7, "Configuring Loudness Settings 1."

- 2. Press START/PAUSE.**

In the upper right of the display, **CM** appears.

- 3. Apply the audio signal.**

Construct the input audio signal as follows:



- Loudness measurement is cleared 1 second after the detection of audio (1 kHz).
- Loudness measurement starts 0.1 seconds after the detection of no audio. The indication in the upper right of the display changes to **MEAS**.
- Loudness measurement stops when the time specified by StopTime elapses after the detection of no audio. If a USB memory device is connected, the loudness data is automatically saved to the device. The indication in the upper right of the display returns to **CM**.

You can measure multiple materials in succession by applying subsequent materials.

9.3.5 File Measurement

In file measurement, measurement is performed while measured values are stored to a USB memory device.

Normally, loudness measurement can be performed up to 24 hours, but file measurement enables measurement that is longer than 24 hours. To do so, follow the procedure below.

1. On the METER 2 tab in the system settings, set Trigger to FILE.

In the upper right of the display, **FILE** appears.

[Reference] METER 2 tab → See section 5.7, “Configuring Loudness Settings 1.”

2. Connect a USB memory device.

3. Press START/PAUSE.

The indication in the upper right of the display changes to **MEAS**, and loudness measurement starts. During measurement, loudness values (gating block loudness) are saved to the USB memory device approximately every 20 s.

```

└─ USB memory device
  └─ LV5838_USER
    └─ TRIG
      └─ yyyyymmddhhmmss.csv
  
```

To stop measurement, press START/PAUSE again. The indication in the upper right of the display returns to **FILE**.

Do not turn the power off or remove the USB memory device while a file measurement is in progress. Doing so may damage the USB memory device.

If you remove the USB memory device or if it becomes full, loudness measurement will automatically stop.

9.3.6 Real Time Measurement

In real time measurement, measurement start and stop are executed according to the times specified on the LV 5838. To perform a measurement, follow the procedure below.

1. On the TIME tab in the system settings, set the date and time.

[Reference] TIME tab → See section 5.13, “Setting the Date and Time.”

2. On the METER 2 tab in the system settings, set Trigger to RealTime, and enter the time code in Trigger Time.

In the top section of the display, “PUSH ‘START’” appears. In the upper right, **RT-P** appears.

In this condition, measurement will not start even when the specified time arrives.

[Reference] METER 2 tab → See section 5.7, “Configuring Loudness Settings 1.”

3. Press START/PAUSE.

In the upper right of the display, **RT** appears. When the specified time arrives, measurement starts or stops automatically. The indicator in the upper right of the display changes to **MEAS** during measurement and returns to **RT** when measurement ends.

10. STATUS DISPLAY

To show the status display, set **F•1** DISPLAY on the mode menu to STATUS.

On the status display, you can use **F•1** DISPLAY MODE of **F•2** STATUS SETUP to display the audio section, SDI section, event log, dBTP log, and PHY.

10.1 Audio Section Display

10.1.1 Audio Section Display Description

In the audio section display, you can press **F•2** DISPLAY to switch the display format between error count, channel status, user bit, Dolby metadata, and Dolby EBI data.

- **Error Count Display**

The LV 5838 counts errors for the items that are enabled on the AUDIO ERROR tab in the system settings (except for validity, which is always counted). Errors are counted up to 9999. You can clear the errors using **F•4** ERROR CLEAR.

“Since Reset” shows the time that has elapsed since the settings were initialized, since the power was turned on, or since **F•4** ERROR CLEAR was pressed.

[Reference] AUDIO ERROR tab → See section 5.10, “Configuring Audio Error Detection Settings.”

F•2 DISPLAY = AUD-STATUS

The screenshot shows the AUDIO STATUS display with the following data:

CH	Over	Clip	Mute	Silence	Parity	CRC	Valid
1/2	0/0	0/0	170/170	3/3	2/2	1/1	OK/OK
3/4	0/0	0/0	2297/2297	52/52	1/1	1/1	OK/OK
5/8	0/0	0/0	2297/2297	52/52	1/1	1/1	OK/OK
7/8	0/0	0/0	2297/2297	52/52	1/1	1/1	OK/OK
9/10	/	/	/	/	/	/	/
11/12	/	/	/	/	/	/	/
13/14	/	/	/	/	/	/	/
15/16	/	/	/	/	/	/	/
Since Reset	00:01:20						

GRP1: *****

Figure 10-1 Error Count Display

10. STATUS DISPLAY

During Dolby E or Dolby Digital measurement, the LV 5838 counts Dolby CRC errors. Moreover, during Dolby E measurement, the LV 5838 measures the frame locations (header location and mode) of the embedded audio signal.

F•2 DISPLAY = AUD-STATUS

```

GRP1: ****
AUDIO STATUS
CH      Over      Clip      Mute      Silence
-----
D1/D2   0/0          0/0       0/0       0/0
D3/D4   0/0          0/0       0/0       0/0
D5/D6   0/0          0/0       0/0       0/0
D7/D8   0/0          0/0       0/0       0/0

DecCH   Parity      CRC       Valid
-----
1/2     0/0          0/0       OK/OK
DolbyCRC: 0      FrLoc V: 36 Mode:20bit
Since Reset 00:00:12
  
```

Figure 10-2 Error Count Display (Option) during Dolby Measurement

- **Channel Status Display**

The channel status display shows the status for the channels that you have selected with the function dial (F•D).

Use **F•6** ALIGN to change the bit order of binary values.

F•2 DISPLAY = CH-STATUS

```

AES/EBU CHANNEL STATUS
DISPLAY CHANNEL 1      Byte : 01234567      01234567
-----
FORMAT      : Professional      00 : 10100001      12 : 00000000
AUDIO DATA : PCM                01 : 00010001      13 : 00000000
EMPHASIS    : No emphasis        02 : 00110100      14 : 00000000
SIGNAL LOCK : Locked             03 : 00000000      15 : 00000000
SAMPLING FREQ: 48kHz           04 : 00000000      16 : 00000000
REFERENCE    : Not reference      05 : 00000000      17 : 00000000
CH MODE      : Two-channel        06 : 00000000      18 : 00000000
                                07 : 00000000      19 : 00000000
RESOLUTION   : 24bits            08 : 00000000      20 : 00000000
ALIGNMENT    : Not indicated      09 : 00000000      21 : 00000000
ORIGIN       :                   10 : 00000000      22 : 00000000
DESTINATION  :                   11 : 00000000      23 : 10100001
TIME-OF-DAY  : 00:00:00
CRC          : NORMAL
  
```

Figure 10-3 Channel status display

- **User Bit Display**

The user bit display shows the user bits for the channels that you have selected with the function dial (F•D).

Use **F•6** ALIGN to change the bit order of binary values.

F•2 DISPLAY = USERBIT

```

AES/EBU USER BIT
DISPLAY CHANNEL 1          Byte : 01234567          01234567
MANAGEMENT : 192-bit      00 : 00000000    12 : 00000000
                          01 : 00000000    13 : 00000000
                          02 : 00000000    14 : 00000000
                          03 : 00000000    15 : 00000000
                          04 : 00000000    16 : 00000000
                          05 : 00000000    17 : 00000000
                          06 : 00000000    18 : 00000000
                          07 : 00000000    19 : 00000000
                          08 : 00000000    20 : 00000000
                          09 : 00000000    21 : 00000000
                          10 : 00000000    22 : 00000000
                          11 : 00000000    23 : 00000000

```

Figure 10-4 User bit display

- **Dolby Metadata Display (option)**

The Dolby metadata display shows meta data during Dolby E or Dolby Digital measurement.

F•2 DISPLAY = DOLBY-META

```

Dolby E Common Metadata Status
Prog Desc Text
Bitstrm Format  DE 20bit      SMPTE Timecode  01:00:00:01
Prog Config    8x1          Framerate       29.97fps
AC-3 Metadata Status
Datarate      Not Specified  Lowpass Filter  off
Bitstrm Mode  Main Complete  LFE Filter      off
Coding Mode   1/0          Srnd Phase Shift off
                          Srnd Attenuator  off
Center Mix Lvl -3.0dB        RF Ov Protect   off
Srnd Mix Lvl  -3.0dB
Dolby Srnd Mode not indicate  Dialnorm Lvl   -27dB
LFE Channel   off
Mix Lvl       not exist
Room Type     not exist
Copyright Bit Not Protected
Orig Bitstrm  Original
DC Filter     off
GRP1: *****

```

Figure 10-5 Dolby metadata display

- **Dolby EBI Data Display (option)**

The Dolby EBI data display shows EBI data during Dolby E or Dolby Digital measurement.

F.2 DISPLAY = DOLBY-EBI

```
AC-3 Extended Bitstream Info                                GRP1: *****
Pref Stereo Downmix Mode  not defined
Lt/Rt Center Mix Lvl     -inf dB
Lt/Rt Srrnd Mix Lvl      -inf dB
Lo/Ro Center Mix Lvl     -inf dB
Lo/Ro Srrnd Mix Lvl      -inf dB

Srrnd EX Mode             not defined
Headphone Mode            not defined
AD Converter Type         HDCD
```

Figure 10-6 Dolby EBI data display

10.1.2 Configuring the Audio Section Display Settings

To configure the audio section display settings, use **F•2** STATUS SETUP on the mode menu and the AUDIO ERROR tab in the system settings. This section explains **F•2** STATUS SETUP. For details on the AUDIO ERROR tab, see section 5.10, “Configuring Audio Error Detection Settings.”




Figure 10-7 STATUS SETUP menu

- **F•2** DISPLAY: **AUD-STATUS** / **CH-STATUS** / **USERBIT** / **DOLBY-META** / **DOLBY-EBI**

Select the display format of the audio section display.

- | | |
|-------------|---|
| AUD-STATUS: | The error count is displayed. |
| CH-STATUS: | The channel status is displayed. |
| USERBIT: | User bits are displayed. |
| DOLBY-META: | The Dolby metadata is displayed. This is available during Dolby E or Dolby Digital measurement. (option). |
| DOLBY-EBI: | Dolby EBI data is displayed. This is available during Dolby E or Dolby Digital measurement. (option). |

- **F•4** ERROR CLEAR

When **F•2** DISPLAY is set to AUD-STATUS, press this key to reset the error counters to zero.

- **F•6** ALIGN: **LSB 1st** / **MSB 1st**

When **F•2** DISPLAY is set to CH-STATUS or USERBIT, press this key to select LSB first or MSB first.

10.2 SDI Section Display

10.2.1 SDI Section Display Description

The SDI section display shows the status of SDI signals. The channel that is displayed is the channel that is currently selected.

Under “SDI,” the presence or absence of SDI signals, format, and embedded channels are displayed.

Under “EMBEDDED AUDIO,” the error counts for the items whose detection has been enabled on the SDI ERROR tab in the system settings are displayed. Errors are counted up to 999,999. You can clear the counters using **F•4** ERROR CLEAR.

[Reference] AUDIO ERROR tab → See section 5.10, “Configuring Audio Error Detection Settings.”




Figure 10-8 SDI section display

10.2.2 Configuring the SDI Section Display Settings

To configure the SDI section display settings, use **F•2** STATUS SETUP on the mode menu and the SDI ERROR tab in the system settings. This section explains the status menu. For details on the SDI ERROR tab, see section 5.11, “Configuring SDI Error Detection Settings.”




Figure 10-9 STATUS SETUP menu

- **F•4** ERROR CLEAR

Press this key to reset the error counters to zero.

10.3 Event Log Display

10.3.1 Event Log Display Description

The event log display shows errors that have occurred in the order of their occurrence. Turning the function dial (F•D) to the right to scroll the screen and view older events in the log. Press the function dial (F•D) to display the latest events.

```

EVENT LOG LIST  SAMPLE No.,= 39  << NOW LOGGING >>  GRP1: *****
39: 2012/09/25 09:47:50 - 10801/59.94
38: 2012/09/25 09:47:48 - 10801/59.94  MUTE:00FF, SIL:00FF,
37: 2012/09/25 09:47:48 A 10801/59.94
36: 2012/09/25 09:47:48 - 10801/59.94  CRC:00FF, MUTE:00FF, P
35: 2012/09/25 09:47:48 A 10801/59.94  A_SMP,
34: 2012/09/25 09:47:48 A 10801/59.94
33: 2012/09/25 09:47:48 - 10801/59.94  MUTE:00FF, SIL:00FF,
32: 2012/09/25 09:47:48 A  NO SIGNAL
31: 2012/09/25 09:47:38 - 10801/59.94
30: 2012/09/25 09:47:38 - 10801/59.94  MUTE:00FC, SIL:00FC,
29: 2012/09/25 09:47:38 - 10801/59.94  CRC:0003, MUTE:00FF, P
28: 2012/09/25 09:47:38 - 10801/59.94  MUTE:00FC, SIL:00FC,
27: 2012/09/25 09:46:50 - BNC
26: 2012/09/25 09:46:49 - BNC  MUTE:0003, SIL:0003,
25: 2012/09/25 09:46:49 - BNC  MUTE:0003, PAR:0003,
24: 2012/09/25 09:46:46 - 10801/59.94
23: 2012/09/25 09:46:46 - 10801/59.94  MUTE:00FC, SIL:00FC,
22: 2012/09/25 09:46:46 - 10801/59.94  CRC:0003, MUTE:00FF, P
21: 2012/09/25 09:46:46 - 10801/59.94  MUTE:00FC, SIL:00FC,
20: 2012/09/25 09:46:43 - BNC
19: 2012/09/25 09:46:43 - BNC  MUTE:0003, SIL:0003,
18: 2012/09/25 09:46:43 - BNC  MUTE:0003, PAR:0003,
17: 2012/09/25 09:46:39 - 10801/59.94
16: 2012/09/25 09:46:39 - 10801/59.94  MUTE:00FF,
15: 2012/09/25 09:46:38 - 10801/59.94  MUTE:00FF, SIL:00FF,
14: 2012/09/25 09:46:38 A 10801/59.94
13: 2012/09/25 09:46:38 - 10801/59.94  CRC:00FF, MUTE:00FF, P
12: 2012/09/25 09:46:38 A 10801/59.94  A_SMP,

```

Figure 10-10 Event log display

- **Time Display**

On the GENERAL tab in the system settings, set TIMECODE SETTING to OFF to log events using the current time or some other setting to log events using the time codes embedded in the input signals.

[Reference] GENERAL tab → See section 5.1, “General Settings.”

- **Format Display**

For external audio signal events, “BNC” is displayed. For embedded audio signal events, the signal format is displayed.

In addition, if an embedded audio error is detected or recovers, the channel is displayed to the left of the format.

- **Error Display**

The errors that may appear on the event log display are listed below.

Only the items whose detection has been enabled on the AUDIO ERROR tab and SDI ERROR tab in the system settings are displayed.

[Reference] AUDIO ERROR tab → See section 5.10, “Configuring Audio Error Detection Settings.”

SDI ERROR tab → See section 5.11, “Configuring SDI Error Detection Settings.”

Table 10-1 Error display

	Error Name	Description
AUDIO ERROR tab	OVER	LevelOver
	CLIP	Clip Error
	MUTE	Mute Error
	SIL	Silence Error
	PAR	Parity Error
	VAL	Validity Error
	CRC	CRC Error
SDI ERROR tab	A_BCH	BCH Error
	A_PRTY	Parity Error
	A_DBN	DBN Error
	A_INH	Inhibit Error
	A_SMP	Sample Number Error

Following the error name on the AUDIO ERROR tab, the channels on which the error occurred are displayed using a hexadecimal number (for example: “MUTE:000C”).

Channels are displayed in order from channel 16. For example, 000C

(0000000000001100) indicates that errors have occurred in channels 3 and 4.

- **Note**

The event log records events are detected for both the external audio signals and embedded audio signals. However, for embedded audio signals, only the currently selected channel is recorded.

If the same error occurs consecutively or if multiple errors occur at the same time, they are treated as a single error.

If multiple errors occur at the same time, you may not be able to view all the events on the screen. If this occurs, you can view all the errors by saving them to a USB memory device.

10.3.2 Configuring Event Log Display Settings

To configure the event log display settings, press **F•2** STATUS SETUP on the mode menu. To select the event log overwrite mode, use the GENERAL tab in the system settings.

[Reference] GENERAL tab → See section 5.1, “General Settings.”




Figure 10-11 STATUS SETUP menu

- **F•2** USBSTORE

Save the event log as a text file to a USB memory device.

This key appears when a USB memory device is connected to the LV 5838.

Log files logs are stored in the following location.

```

├── USB memory device
│   └── LV5838_USER
│       ├── LOG
│       └── yyyyymmddhhmmss.txt

```

- **F•3** LOG: STOP / START

Select event log start or stop.

“LOG” is displayed in the upper right of the screen when errors are being logged.

- **F•4** LOG CLEAR

Clear the event log. The log is also cleared when you turn the power off.

10.4 dBTP Log Display

A dBTP log records time-series data of a channel when the peak level exceeds the threshold during loudness measurement. To enable the dBTP log, set dBTP OVER MARK to ON on the METER 3 tab in the system settings, and then start the loudness measurement. (Nothing is recorded when the loudness measurement is stopped.)

The threshold is the LevelOver value specified on the AUDIO ERROR tab in the system settings.

The dBTP log can record up to 1000 entries. When this limit is exceeded, the oldest data is overwritten.

The log cannot be recorded when the audio mode is 5.1 DM.

[Reference] METER 3 tab → See section 5.8, “Configuring Loudness Settings 2.”

AUDIO ERROR tab → See section 5.10, “Configuring Audio Error Detection Settings.”

10.4.1 dBTP Log Display Description

By turning the function dial (F•D) to the right, you can scroll the screen to view older entries in the log. Press the function dial (F•D) to display the latest entries in the log.

```

LOUDNESS dBTP LOG LIST  SAMPLE No.= 30  GRP1:-17.3  GRP2:-16.7
Level Over -1dBTP
30: 2013/02/28 11:18:58 GR2
29: 2013/02/28 11:18:58 GR1
28: 2013/02/28 11:18:58 GR2 L, R, C, LFE, LS, RS,
27: 2013/02/28 11:18:58 GR1 L, R,
26: 2013/02/28 11:18:18 GR2
25: 2013/02/28 11:18:18 GR1
24: 2013/02/28 11:18:18 GR2 L,
23: 2013/02/28 11:18:18 GR1 L, R, C, LFE, LS, RS,
22: 2013/02/28 11:18:04 GR2
21: 2013/02/28 11:18:04 GR1
20: 2013/02/28 11:18:00 GR2 L, R, C, LFE, LS, RS,
19: 2013/02/28 11:18:00 GR1 L, R, C, LFE, LS, RS,
18: 2013/02/28 11:17:09 GR2
17: 2013/02/28 11:17:09 GR1
16: 2013/02/28 11:17:08 GR2 L,
15: 2013/02/28 11:17:08 GR1 L, R,
14: 2013/02/28 11:15:36 GR2
13: 2013/02/28 11:15:36 GR1
12: 2013/02/28 11:15:36 GR2 L, R, C, LFE, LS, RS,
11: 2013/02/28 11:15:36 GR1 L,
10: 2013/02/28 11:15:28 GR2
9: 2013/02/28 11:15:28 GR1
8: 2013/02/28 11:15:28 GR2 L, R, C, LFE, LS, RS,
7: 2013/02/28 11:15:28 GR1 L,
6: 2013/02/28 11:04:23 GR1
5: 2013/02/28 11:04:22 GR1 L,
4: 2013/02/28 11:04:06 GR1
3: 2013/02/28 11:04:05 GR1 L, R,

```

Figure 10-12 dBTP log display

- **Level Over Display**

The LevelOver value specified on the AUDIO ERROR tab in the system settings is displayed.

[Reference] AUDIO ERROR tab → See section 5.10, “Configuring Audio Error Detection Settings.”

- **Time Display**

On the GENERAL tab in the system settings, set TIMECODE SETTING to OFF to log events using the current time or some other setting to log events using the time codes embedded in the input signals.

[Reference] GENERAL tab → See section 5.1, “General Settings.”

- **Group Display**

Audio groups in which “level over” occurs are displayed as GR1 or GR2.

- **Channel Display**

Channels in which “level over” occurs are displayed here.

10.4.2 Configuring dBTP Log Display Settings

To configure the dBTP log display settings, press **F•2** STATUS SETUP on the mode menu.

MODE → **F•1** DISPLAY to STATUS → **F•2** STATUS SETUP → **F•1** DISPLAY MODE to dBTP LOG →




Figure 10-13 STATUS SETUP menu

- **F•2 USBSTORE**

Save the dBTP log as a text file to a USB memory device.

This key appears when a USB memory device is connected to the LV 5838.

Log files logs are stored in the following location.



- **F•4 LOG CLEAR**

Clear the dBTP log. The log is also cleared when you hold down CLEAR or turn the power off.

10.5 PHY Display

10.5.1 PHY Display Description

The PHY display shows the amplitude of the external audio signals, the audio frequency error relative to the reference signal, and the sampling frequency.




Figure 10-14 PHY display

- **Src**

The relative frequency measurement reference signal that you selected with **F•2** SOURCE is displayed.

- **Amp**

Simplified amplitude measurement is performed on external audio signals and displayed in Vp-p. This does not appear during SDI measurement.

- **Sync**

The relative frequency measurement results are displayed as follows:

- *OK*: Equal to the reference signal
- OK: The relative frequency error is within ± 1 ppm.
- NG: The relative frequency error exceeds ± 1 ppm.

- **Relative Frequency Display**

The frequency errors relative to the reference signal are displayed using indicators and numeric values (ppm).

The right side of the indicators represents -5 ppm, the left side represents +5 ppm, and the center represents 0 ppm.

- **PHY FREQ**

The physical sampling frequency of input signals is detected and displayed.

- **STATUS FREQ**

The sampling frequency information in channel status is displayed.

10.5.2 Configuring the PHY Display Settings

To configure the PHY display settings, press **F•2** STATUS SETUP on the mode menu.

MODE → **F•1** DISPLAY to STATUS → **F•2** STATUS SETUP → **F•1** DISPLAY MODE to PHY →




Figure 10-15 STATUS SETUP menu

- **F•2** SOURCE: **CH1/2** / **CH3/4** / **CH5/6** / **CH7/8** / **CH9/10** / **CH11/12** / **CH13/14** / **CH15/16** / **EXT-SYNC**

Select the signal to use as the frequency measurement reference. If you select EXT-SYNC, select the format on the GENERAL tab in the system settings, and apply an external reference signal to the EXT REF INPUT connector on the rear panel.

[Reference] GENERAL tab → See section 5.1, “General Settings.”

11. REMOTE CONTROL

You can use the remote control connector on the rear panel to load presets, transmit alarm signals, and perform other operations. Use the supplied 15-pin D-sub connector to control the LV 5838.

● Pinout

This section contains a diagram of the remote control connector, displayed as it appears on the rear panel, and a table that describes the connector's pinout.

The pinout varies depending on the Select setting on the ETHER&REMOTE tab in the system settings.

[Reference] ETHER&REMOTE tab → See section 5.2, "Configuring the Ethernet and Remote Settings."




Figure 11-1 Remote control connector

Table 11-1 Remote control connector pinout

Pin No.	I/O	Select		
		Recall	Recall and 5838_02	5838_01+02
1	O	+5 V power supply (*1)	+5 V power supply (*1)	+5 V power supply (*1)
2	I	NOT USE	Start/stop loudness measurement (*2)	Start/stop loudness measurement (*2)
3	I	NOT USE	NOT USE	NOT USE
4	I	NOT USE	Clear the loudness measurement (*2)	Clear the loudness measurement (*2)
5	I	NOT USE	NOT USE	NOT USE
6	I	Recall preset 1	Recall preset 1	G1:STEREO / G2:OFF (*3)
7	I	Recall preset 2	Recall preset 2	G1:MONO / G2:OFF (*3)
8	I	Recall preset 3	Recall preset 3	G1:5.1 / G2:OFF (*3)
9	I	Recall preset 4	Recall preset 4	G1:STEREO / G2:STEREO (*3)
10	I	Recall preset 5	Recall preset 5	G1:MONO / G2:MONO (*3)
11	I	NOT USE	NOT USE	G1:STEREO / G2:MONO (*3)
12	I	NOT USE	NOT USE	G1:5.1 / G2:STEREO (*3)
13	I	NOT USE	NOT USE	NOT USE
14	O	Alarm output	Alarm output	Alarm output
15	-	Ground	Ground	Ground

*1 Used with the LV 5838-01 (REMOTE CONTROLLER) and LV 5838-02 (REMOTE CONTROLLER), which are sold separately. Do not use this for any other purpose.

*2 You must set Trigger on the METER 2 tab in the system settings to Remote. Connect a LV 5838-02 to control these operations using buttons.

*3 G1 and G2 indicate GROUP1 and GROUP2 on the assign menu. Connect a LV 5838-01 to control these operations using buttons.

* Do not connect anything to the pins indicated as NOT USE.

● **Configuring the LV 5838**

To set the remote control connector, use the ETHER&REMOTE tab in the system settings.
 [Reference] ETHER&REMOTE tab → See section 5.2, “Configuring the Ethernet and Remote Settings.”

SYSTEM → F.1 SYSTEM SETUP → F.3 NEXT TAB →

GENERAL	ETHER&REMOTE	ETC				
ETHERNET SETTING						
Ethernet	<input type="checkbox"/> DHCP <input checked="" type="checkbox"/> IP					
IP Address	<table border="1"><tr><td>192</td><td>168</td><td>0</td><td>1</td></tr></table>	192	168	0	1	MAC ADDRESS
192	168	0	1			
Subnet Mask	<table border="1"><tr><td>255</td><td>255</td><td>255</td><td>0</td></tr></table>	255	255	255	0	00:00:00:00:00:00
255	255	255	0			
Gateway	<table border="1"><tr><td>0</td><td>0</td><td>0</td><td>0</td></tr></table>	0	0	0	0	
0	0	0	0			
TIME SERVER SETTING						
Time Server	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF	Time Zone				
IP Address	<table border="1"><tr><td>0</td><td>0</td><td>0</td><td>0</td></tr></table>	0	0	0	0	+09:00
0	0	0	0			
SNMP SETTING						
SNMP	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF					
ACCESS	<input checked="" type="checkbox"/> RO <input type="checkbox"/> RW					
SNMP Trap	<input checked="" type="checkbox"/> OFF <input type="checkbox"/> ON					
REMOTE SETTING						
Alarm Polarity	<input checked="" type="checkbox"/> Positive <input type="checkbox"/> Negative					
Select	<input checked="" type="checkbox"/> Recall <input type="checkbox"/> Recall and 5838_02 <input type="checkbox"/> 5838_01+02					

Figure 11-2 ETHER&REMOTE tab

● **Control**

The input connectors respond to active-low signals. Do not apply negative voltages or voltages that exceed +5 V. The active-low signal must be stable for at least 350 ms. After that, wait at least 1 second before applying the next signal.




Figure 11-3 Remote control timing 1

After a setting is made, it may take about 3 seconds for the operation to finish. If you configure subsequent settings before the initial operation finishes, only the last setting will take effect. All settings in between will be discarded. (In the following example, control 2 will be discarded.)




Figure 11-4 Remote control timing 2

12. ETHERNET CONTROL

The LV 5838 can be remotely controlled through its Ethernet port on the rear panel.

Controlling an LV 5838 remotely through its Ethernet interface has only been confirmed to work in a local network environment. LEADER does not guarantee that this feature will work in any network environment.

12.1 TELNET

From a PC connected to the same network as the LV 5838, you can remotely control most of the operations that can be controlled from the panel.

12.1.1 Procedure

1. On the ETHER&REMOTE tab, set the IP address.

[Reference] See section 5.2, “Configuring the Ethernet and Remote Settings.”

SYSTEM → F•1 SYSTEM SETUP → F•3 NEXT TAB →

GENERAL	ETHER&REMOTE	ETC				
ETHERNET SETTING						
Ethernet	<input type="checkbox"/> DHCP <input checked="" type="checkbox"/> IP					
IP Address	<table border="1"><tr><td>192</td><td>168</td><td>0</td><td>1</td></tr></table>	192	168	0	1	MAC ADDRESS
192	168	0	1			
Subnet Mask	<table border="1"><tr><td>255</td><td>255</td><td>255</td><td>0</td></tr></table>	255	255	255	0	00:00:00:00:00:00
255	255	255	0			
Gateway	<table border="1"><tr><td>0</td><td>0</td><td>0</td><td>0</td></tr></table>	0	0	0	0	
0	0	0	0			
TIME SERVER SETTING						
Time Server	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF	Time Zone				
IP Address	<table border="1"><tr><td>0</td><td>0</td><td>0</td><td>0</td></tr></table>	0	0	0	0	+09:00
0	0	0	0			
SNMP SETTING						
SNMP	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF					
ACCESS	<input checked="" type="checkbox"/> RO <input type="checkbox"/> RW					
SNMP Trap	<input checked="" type="checkbox"/> OFF <input type="checkbox"/> ON					
REMOTE SETTING						
Alarm Polarity	<input checked="" type="checkbox"/> Positive <input type="checkbox"/> Negative					
Select	<input checked="" type="checkbox"/> Recall <input type="checkbox"/> Recall and 5838_02 <input type="checkbox"/> 5838_01+02					

Figure 12-1 ETHER&REMOTE tab

2. Press F•1 COMPLETE.

3. Restart the LV 5838.

If you didn't make any changes, you do not have to restart.

4. Connect the LV 5838's Ethernet port to the network.

Use a UTP cable (category 5).

5. On the PC, start a TELNET client.

On Windows 7, on the taskbar, click Start, and then click Run. Type “TELNET “ and the IP address that you set in step 1. Then, click OK.

(To use TELNET, open Control Panel, click Turn Windows features on or off under Program and Features, and select the Telnet Client check box.)

6. Type the login name and password.

The login name and password are "LV5838". Use uppercase for all characters. When the login name and password are entered correctly, "LV5838>" appears.

```
login: LV5838
Password: *****
LV5838>
```

7. Enter TELNET commands.

Enter commands by referring to sections 12.1.2, "How to Enter Commands," and 12.1.3, "TELNET Commands."

To end a TELNET session, type "bye" in lowercase letters.

```
LV5838> bye
```

12.1.2 How to Enter Commands

The command syntax is explained below. (Some commands do not have parameters.) To query a current setting, use a question mark as the parameter.

```
LV5838> [Command] + [Space] + [Parameter]
```

Examples of how to enter commands are shown below.

```
LV5838> LOUD_CLEAR..... Clear the loudness measurement.

LV5838> MODE:DISPLAY STATUS ..... Set the display mode to status.

LV5838> SYSTEM:TIMECODE ?..... Query the time code type.
OFF ..... Return value
LV5838>
```

- * You can enter commands using uppercase or lowercase letters.
- * Commands that begin with "MODE" only apply to the area (1 or 2) that is specified by the WIN command.
- * When using TELNET, enable flow control.
If your Telnet client does not support flow control, the LV 5838 may not operate properly when commands are transferred at a high speed. In such case, allow about 1 second between command transmissions.

12.1.3 TELNET Commands

TELNET commands follow the LV 5838 menu structure. For explanations of each item, see the LV 5838 instruction manual. Depending on the current settings, some of the items that are described in this manual may be invalid.

Table 12-1 LV 5838 commands

Command	Parameter
INPUT	A / B / ?
AES	SDI / EXT / ?
WIN	1 / 2 / ?
MULTI	-
LOUDNESS	START / PAUSE / ?
LOUD_STORE	-
LOUD_CLEAR	-
RECALL	1 to 5
DATE	YEAR MONTH DAY HOUR MINUTE SECOND / ?
VOLUME	0 to 127 / ?

Table 12-2 Assign commands

Command	Parameter
ASSIGN:MODE:GROUP1	MONO / STEREO / 5.1 / 5.1_DM / CUSTOM / ?
ASSIGN:MODE:GROUP2	OFF / MONO / STEREO / 5.1 / 5.1_DM / CUSTOM / ?
ASSIGN:PHONES_L	CH1 to CH16 / DOLBY1 to DOLBY8 / DOLBY_AUX / ?
ASSIGN:PHONES_R	CH1 to CH16 / DOLBY1 to DOLBY8 / DOLBY_AUX / ?
ASSIGN:AUX_CH	LT/RT / LO/RO / MONO / MUTE / ?
ASSIGN:AUX_CH_DRC	LINE / RF / ?
ASSIGN:GROUP1:L	CH1 to CH16 / NON_CONNECT / ?
ASSIGN:GROUP1:R	CH1 to CH16 / NON_CONNECT / ?
ASSIGN:GROUP1:C	CH1 to CH16 / NON_CONNECT / ?
ASSIGN:GROUP1:LFE	CH1 to CH16 / NON_CONNECT / ?
ASSIGN:GROUP1:LS	CH1 to CH16 / NON_CONNECT / ?
ASSIGN:GROUP1:RS	CH1 to CH16 / NON_CONNECT / ?
ASSIGN:GROUP2:L	CH1 to CH16 / NON_CONNECT / ?
ASSIGN:GROUP2:R	CH1 to CH16 / NON_CONNECT / ?
ASSIGN:GROUP2:C	CH1 to CH16 / NON_CONNECT / ?
ASSIGN:GROUP2:LFE	CH1 to CH16 / NON_CONNECT / ?
ASSIGN:GROUP2:LS	CH1 to CH16 / NON_CONNECT / ?
ASSIGN:GROUP2:RS	CH1 to CH16 / NON_CONNECT / ?

Table 12-3 Mode commands

Command	Parameter
MODE:DISPLAY	METER / LISSAJOU / SURROUND / LOUDNESS / STATUS / ?
MODE:METER:RESPONSE	TRUEPEAK / PPM(I) / PPM(II) / VU / ?
MODE:METER:PEAKHOLD	OFF / TRUEPEAK / PPM(I) / PPM(II) / ?

12. ETHERNET CONTROL

Command	Parameter
MODE:METER:PEAKHOLD_TIME	0.0 / 0.5 / 1.0 / 2.0 / 3.0 / 4.0 / 5.0 / HOLD / ?
MODE:METER:SCALE_MAG	OFF / ON / ?
MODE:METER:GROUP	GROUP1 / GROUP2 / ALL / 1-8 / 9-16 / ?
MODE:LISSAJOU:MONO	CH1 to CH16 / ?
MODE:LISSAJOU:L	CH1 to CH16 / ?
MODE:LISSAJOU:R	CH1 to CH16 / ?
MODE:LISSAJOU:AUTOGAIN	ON / OFF / ?
MODE:LISSAJOU:GROUP	GROUP1 / GROUP2 / ALL / 1-8 / 9-16 / ?
MODE:SURROUND:DISPLAY	BOTH / LISSAJOU / SURROUND / ?
MODE:SURROUND:MODE	NORMAL / PHANTOM / ?
MODE:SURROUND:AUTOGAIN	ON / OFF / ?
MODE:SURROUND:GROUP	GROUP1 / GROUP2 / ?
MODE:LOUDNESS:DISPLAY	CHART / BAR / NUM / NUM_ONLY / METER / ?
MODE:LOUDNESS:SCALE	OFF / 1MIN / 4MIN / 10MIN / 30MIN / 1HOUR / 2HOUR / 4HOUR / 6HOUR / 12HOUR / 24HOUR / ?
MODE:LOUDNESS:SCALE_CHART	1MIN / 4MIN / 10MIN / 30MIN / 1HOUR / 2HOUR / 4HOUR / 6HOUR / 12HOUR / 24HOUR / ?
MODE:LOUDNESS:SELECT	INTEGRATED / MOMENTARY / SHORTTERM / ALL / ?
MODE:LOUDNESS:STYLE	VERT / HORI / ?
MODE:LOUDNESS:SCALE_MAG_BAR	OFF / WIDE / NARROW / ?
MODE:LOUDNESS:SCALE_MAG_METER	WIDE / NARROW / ?
MODE:LOUDNESS:GROUP	GROUP1 / GROUP2 / ?
MODE:STATUS:MODE	AUD-SEC / SDI-SEC / EVENTLOG / LOUD_LOG / PHY / ?
MODE:STATUS:DISPLAY	AUD-STATUS / CH-STATUS / USERBIT / DOLBY-META / DOLBY-EBI / ?
MODE:STATUS:SCALE	50MS / 100MS / 500MS / 1.0S / 2.5S / ?
MODE:STATUS:SOURCE	AESEBU / SDI-ANC / ?
MODE:STATUS:CH-STATUS:CH	1 to 16 / ?
MODE:STATUS:CH-STATUS:ALIGN	LSB / MSB / ?
MODE:STATUS:USERBIT:CH	1 to 16 / ?
MODE:STATUS:USERBIT:ALIGN	LSB / MSB / ?
MODE:STATUS:META:PROGRAM	PRM1 / PRM2 / PRM3 / PRM4 / PRM5 / PRM6 / PRM7 / PRM8 / ?
MODE:STATUS:EBI:PROGRAM	PRM1 / PRM2 / PRM3 / PRM4 / PRM5 / PRM6 / PRM7 / PRM8 / ?
MODE:STATUS:EVENTLOG	STOP / START / ?
MODE:STATUS:PHY:SOURCE	CH1/2 / CH3/4 / CH5/6 / CH7/8 / CH9/10 / CH11/12 / CH13/14 / CH15/16 / EXT-SYNC / ?

Table 12-4 System commands

Command	Parameter
SYSTEM:EXTERNAL:SDI	INPUT / OUTPUT / ?
SYSTEM:EXTERNAL:AES	INPUT / OUTPUT / ?
SYSTEM:TIMECODE	OFF / LTC / VITC / D_VITC / AESEBU / LTC-EXT / ?

12. ETHERNET CONTROL

Command	Parameter
SYSTEM:SRC:FLAG	ON / OFF / ?
SYSTEM:SRC:CH	CH1_2 / CH3_4 / CH5_6 / CH7_8 / CH9_10 / CH11_12 / CH13_14 / CH15_16 / INTERNAL / ?
SYSTEM:EXTREF:INPUT	VIDEO_SYNC / WORDCLOCK / CW / ?
SYSTEM:EXTREF:CLOCK	48KHZ / 44.1KHZ / 32KHZ / ?
SYSTEM:EXTREF:TERMINATION	75 / 20K / ?
SYSTEM:LOGMODE	OVERWRITE / STOP / ?
SYSTEM:SETTING:WARNING	-40 to 0 / ?
SYSTEM:SETTING:REFERENCE	-40 to 0 / ?
SYSTEM:SCALE	DBFS / NORDIC / DIN / BBC / ?
SYSTEM:LOUD:MEASURE	BS1770-2 / ARIB / EBU / ATSC / CUSTOM / ?
SYSTEM:LOUD:TARGET:LEVEL	-99 to 0 / ?
SYSTEM:LOUD:LFE_GAIN	0 to 10 (in steps of 0.5) / ?
SYSTEM:LOUD:BLOCKSIZE	200 to 30000 (in steps of 50) / ?
SYSTEM:LOUD:OVERLAPSIZE	0 to 99 / ?
SYSTEM:LOUD:ABSOLUTE:FLAG	ON / OFF / ?
SYSTEM:LOUD:ABSOLUTE:LEVEL	-99 to 0 / ?
SYSTEM:LOUD:RELATIVE:FLAG	ON / OFF / ?
SYSTEM:LOUD:RELATIVE:LEVEL	-99 to 0 / ?
SYSTEM:LOUD:SHORTTERM:AVERAGE	200 to 30000 (in steps of 50) / ?
SYSTEM:LOUD:MOMENTARY:AVERAGE	100 to 1000 (in steps of 25) / ?
SYSTEM:LOUD:RANGE:AVERAGE (to be supported in the future)	200 to 30000 (in steps of 50) / ?
SYSTEM:LOUD:RANGE:OVERLAP (to be supported in the future)	0 to 99 / ?
SYSTEM:LOUD:MARK:OVER	ON / OFF / ?
SYSTEM:LOUD:MARK:RELATIVE	ON / OFF / ?
SYSTEM:ERROR:OVER:FLAG	ON / OFF / ?
SYSTEM:ERROR:OVER:LEVEL	-40 to 0 / ?
SYSTEM:ERROR:CLIP:FLAG	ON / OFF / ?
SYSTEM:ERROR:CLIP:DURATION	1 to 100 / ?
SYSTEM:ERROR:MUTE:FLAG	ON / OFF / ?
SYSTEM:ERROR:MUTE:DURATION	1 to 100 (in steps of 10) / ?
SYSTEM:ERROR:MUTE:LEVEL	-99 to -60 / ?
SYSTEM:ERROR:SILENT:FLAG	ON / OFF / ?
SYSTEM:ERROR:SILENT:DURATION	1 to 5000 (in steps of 10) / ?
SYSTEM:ERROR:FRAME:FLAG (to be supported in the future)	ON / OFF / ?
SYSTEM:ERROR:FRAME:GUARDBAND (to be supported in the future)	RDD6 / CUSTOM / ?
SYSTEM:ERROR:FRAME:SD_MIN (to be supported in the future)	8 to 30 / ?
SYSTEM:ERROR:FRAME:SD_MAX (to be supported in the future)	8 to 30 / ?
SYSTEM:ERROR:FRAME:HD_MIN	8 to 30 / ?

12. ETHERNET CONTROL

Command	Parameter
(to be supported in the future)	
SYSTEM:ERROR:FRAME:HD_MAX (to be supported in the future)	8 to 30 / ?
SYSTEM:ERROR:PARITY	ON / OFF / ?
SYSTEM:ERROR:VALIDITY	ON / OFF / ?
SYSTEM:ERROR:CRC	ON / OFF / ?
SYSTEM:ERROR:DOLBY_CRC	ON / OFF / ?
SYSTEM:ERROR:AUDIO:BCH	ON / OFF / ?
SYSTEM:ERROR:AUDIO:PARITY	ON / OFF / ?
SYSTEM:ERROR:AUDIO:DBN	ON / OFF / ?
SYSTEM:ERROR:AUDIO:INHIBIT	ON / OFF / ?
SYSTEM:ERROR:AUDIO:SAMPLE	ON / OFF / ?
SYSTEM:DOLBY:MODULE	OFF / DOLBY-E / DOLBY-DIGITAL / DOLBY-DIGITAL-PLUS / ?
SYSTEM:DOLBY:INPUT	CH1_2 / CH3_4 / CH5_6 / CH7_8 / CH9_10 / CH11_12 / CH13_14 / CH15_16 / ?
SYSTEM:DOLBY:E:DIALONORM	OFF / ON / ?
SYSTEM:DOLBY:E:PULLDOWN	OFF / ON / ?
SYSTEM:DOLBY:DIGITAL:LISTENING	FULL / EX / 3STEREO / PHANTOM / STEREO / MONO / ?
SYSTEM:DOLBY:DIGITAL:PROLOGIC	OFF / ON / ?
SYSTEM:DOLBY:DIGITAL:DRC	BYPASS / LINE / RF / ?

12.2 SNMP

By using SNMP (Simple Network Management Protocol), you can control an LV 5838 from SNMP managers. Additionally, you can notify the SNMP managers of errors that the LV 5838 generates.

The LV 5838 supports SNMPv1.

12.2.1 SMI Definitions

IMPORTS

MODULE-IDENTITY, OBJECT-TYPE, NOTIFICATION-TYPE, enterprises
FROM SNMPv2-SMI

DisplayString

FROM SNMPv2-TC

OBJECT-GROUP, MODULE-COMPLIANCE

FROM SNMPv2-CONF;

12.2.2 Procedure

1. Configure the Ethernet settings on the ETHER&REMOTE tab of the LV 5838.

Set the IP Address, set SNMP to ON, ACCESS to RW, and SNMP Trap to ON.

[Reference] See section 5.2, "Configuring the Ethernet and Remote Settings."

SYSTEM → F•1 SYSTEM SETUP → F•3 NEXT TAB →

GENERAL	ETHER&REMOTE	ETC				
ETHERNET SETTING						
Ethernet	<input type="checkbox"/> DHCP <input checked="" type="checkbox"/> IP					
IP Address	<table border="1"><tr><td>192</td><td>168</td><td>0</td><td>1</td></tr></table>	192	168	0	1	MAC ADDRESS
192	168	0	1			
Subnet Mask	<table border="1"><tr><td>255</td><td>255</td><td>255</td><td>0</td></tr></table>	255	255	255	0	00:00:00:00:00:00
255	255	255	0			
Gateway	<table border="1"><tr><td>0</td><td>0</td><td>0</td><td>0</td></tr></table>	0	0	0	0	
0	0	0	0			
TIME SERVER SETTING						
Time Server	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF	Time Zone				
IP Address	<table border="1"><tr><td>0</td><td>0</td><td>0</td><td>0</td></tr></table>	0	0	0	0	+09:00
0	0	0	0			
SNMP SETTING						
SNMP	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF					
ACCESS	<input type="checkbox"/> RO <input checked="" type="checkbox"/> RW					
SNMP Trap	<input type="checkbox"/> OFF <input checked="" type="checkbox"/> ON					
REMOTE SETTING						
Alarm Polarity	<input checked="" type="checkbox"/> Positive <input type="checkbox"/> Negative					
Select	<input checked="" type="checkbox"/> Recall <input type="checkbox"/> Recall and 5838_02 <input type="checkbox"/> 5838_01+02					

Figure 12-2 ETHER&REMOTE tab

2. Press F•1 COMPLETE.

3. Restart the LV 5838.

If you didn't make any changes, you do not have to restart.

4. Connect the LV 5838's Ethernet port to the network.

Use a UTP cable (category 5).

5. On the PC, start an SNMP manager.

You must provide the SNMP manager yourself.
The community name is shown below.

Read community: LDRUser
Write community: LDRAdm
TRAP community: LDRUser

6. Check that the SNMP managers can perform GET and SET operations.**7. From the SNMP manager, set the following MIB items to the SNMP managers' IP addresses.**

Up to four locations can be set.

[IP address of TRAP transmission destination 1]

1.3.6.1.4.1.leader(20111).lv5838(25).lv5838ST1(1).I25trapTBL(5).I25trapIpTBL(2).I25trapIp1TBL(1).I25trapManagerIp1(1).0

[IP address of TRAP transmission destination 2]

1.3.6.1.4.1.leader(20111).lv5838(25).lv5838ST1(1).I25trapTBL(5).I25trapIpTBL(2).I25trapIp2TBL(2).I25trapManagerIp2(1).0

[IP address of TRAP transmission destination 3]

1.3.6.1.4.1.leader(20111).lv5838(25).lv5838ST1(1).I25trapTBL(5).I25trapIpTBL(2).I25trapIp3TBL(3).I25trapManagerIp3(1).0

[IP address of TRAP transmission destination 4]

1.3.6.1.4.1.leader(20111).lv5838(25).lv5838ST1(1).I25trapTBL(5).I25trapIpTBL(2).I25trapIp4TBL(4).I25trapManagerIp4(1).0

8. Enable the TRAP transmission destinations.

To alleviate communication load, disable the transmission destinations that you are not using. This setting is disabled by factory default.

[Enable (2) or disable (1) TRAP transmission destination 1]

1.3.6.1.4.1.leader(20111).lv5838(25).lv5838ST1(1).I25trapTBL(5).I25trapIpTBL(2).I25trapIp1TBL(1).I25trapManagerIp1Act(2).0

[Enable (2) or disable (1) TRAP transmission destination 2]

1.3.6.1.4.1.leader(20111).lv5838(25).lv5838ST1(1).I25trapTBL(5).I25trapIpTBL(2).I25trapIp2TBL(2).I25trapManagerIp2Act(2).0

[Enable (2) or disable (1) TRAP transmission destination 3]

1.3.6.1.4.1.leader(20111).lv5838(25).lv5838ST1(1).I25trapTBL(5).I25trapIpTBL(2).I25trapIp3TBL(3).I25trapManagerIp3Act(2).0

[Enable (2) or disable (1) TRAP transmission destination 4]

1.3.6.1.4.1.leader(20111).lv5838(25).lv5838ST1(1).I25trapTBL(5).I25trapIpTBL(2).I25trapIp4TBL(4).I25trapManagerIp4Act(2).0

9. Restart the LV 5838.**10. When the LV 5838 starts, it transmits the standard TRAP "coldStart(0)." Check that this is received by the SNMP managers.**

12.2.3 Standard MIB

The LV 5838 uses the following standard MIBs:

- RFC1213 (MIB-II)
- RFC1354 (IP Forwarding Table MIB)

In the tables, “ACCESS” and “SUPPORT” indicate the following:

	Indication	Description
ACCESS	R/O	Information that can be read from the SNMP managers.
	R/W	Information that can be read and written from the SNMP managers.
SUPPORT	○	Supports the MIB object as defined by the standard.
	△	Reading and writing are possible according to the standard, but the LV 5838 only supports reading.
	×	Not supported.

Table 12-5 system group

MIB	OID	SYNTAX	ACCESS	SUPPORT
sysDescr	system.1	DisplayString	R/O	○
sysObjectID	system.2	ObjectID	R/O	○
sysUpTime	system.3	TimeTicks	R/O	○
sysContact (*1)	system.4	DisplayString	R/W	○
sysName (*1)	system.5	DisplayString	R/W	○
sysLocation (*1)	system.6	DisplayString	R/W	○
sysServices	system.7	INTEGER	R/O	○

*1 Set using up to 40 bytes.

Table 12-6 interface group

MIB	OID	SYNTAX	ACCESS	SUPPORT
ifNumber	interfaces.1	INTEGER	R/O	○
ifTable	interfaces.2	Aggregate	-	○
ifEntry	ifTable.1	Aggregate	-	○
ifIndex	ifEntry.1	INTEGER	R/O	○
ifDescr	ifEntry.2	DisplayString	R/O	○
ifType	ifEntry.3	INTEGER	R/O	○
ifMtu	ifEntry.4	INTEGER	R/O	○
ifSpeed	ifEntry.5	Gauge	R/O	○
ifPhysAddress	ifEntry.6	DisplayString	R/O	○
ifAdminStatus	ifEntry.7	INTEGER	R/O	△
ifOperStatus	ifEntry.8	INTEGER	R/O	△
ifLastChange	ifEntry.9	TimeTicks	R/O	○
ifInOctets	ifEntry.10	Counter	R/O	○
ifInUcastPkts	ifEntry.11	Counter	R/O	○
ifInNUcastPkts	ifEntry.12	Counter	R/O	○
ifInDiscards	ifEntry.13	Counter	R/O	○
ifInErrors	ifEntry.14	Counter	R/O	○

12. ETHERNET CONTROL

MIB	OID	SYNTAX	ACCESS	SUPPORT
ifInUnknownProtos	ifEntry.15	Counter	R/O	○
ifOutOctets	ifEntry.16	Counter	R/O	○
ifOutUcastPkts	ifEntry.17	Counter	R/O	○
ifOutNUcastPkts	ifEntry.18	Counter	R/O	○
ifOutDiscards	ifEntry.19	Counter	R/O	○
ifOutErrors	ifEntry.20	Counter	R/O	○
ifOutQLen	ifEntry.21	Gauge	R/O	○
ifSpecific	ifEntry.22	ObjectID	R/O	○

Table 12-7 ip group

MIB	OID	SYNTAX	ACCESS	SUPPORT
ipForwarding	ip.1	INTEGER	R/O	○
ipDefaultTTL	ip.2	INTEGER	R/O	○
ipInReceives	ip.3	Counter	R/O	○
ipInHdrErrors	ip.4	Counter	R/O	○
ipInAddrErrors	ip.5	Counter	R/O	○
ipForwDatagrams	ip.6	Counter	R/O	○
ipInUnknownProtos	ip.7	Counter	R/O	○
ipInDiscards	ip.8	Counter	R/O	○
ipInDelivers	ip.9	Counter	R/O	○
ipOutRequests	ip.10	Counter	R/O	○
ipOutDiscards	ip.11	Counter	R/O	○
ipOutNoRoutes	ip.12	Counter	R/O	○
ipReasmTimeout	ip.13	INTEGER	R/O	○
ipReasmReqds	ip.14	Counter	R/O	○
ipReasmOKs	ip.15	Counter	R/O	○
ipReasmFails	ip.16	Counter	R/O	○
ipFragOKs	ip.17	Counter	R/O	○
ipFragFails	ip.18	Counter	R/O	○
ipFragCreates	ip.19	Counter	R/O	○
ipAddrTable	ip.20	Aggregate	-	○
ipAddrEntry	ipAddrTable.1	Aggregate	-	○
ipAdEntAddr	ipAddrEntry.1	IpAddress	R/O	○
ipAdEntIfIndex	ipAddrEntry.2	INTEGER	R/O	○
ipAdEntNetMask	ipAddrEntry.3	IpAddress	R/O	○
ipAdEntBcastAddr	ipAddrEntry.4	INTEGER	R/O	○
ipAdEntReasmMaxSize	ipAddrEntry.5	INTEGER	R/O	○
ipNetToMediaTable	ip.22	Aggregate	-	○
ipNetToMediaEntry	ipNetToMediaTable.1	Aggregate	-	○
ipNetToMediaIfIndex	ipNetToMediaEntry.1	INTEGER	R/O	△
ipNetToMediaPhysAddress	ipNetToMediaEntry.2	DisplayString	R/O	△
ipNetToMediaNetAddress	ipNetToMediaEntry.3	IpAddress	R/O	△
ipNetToMediaType	ipNetToMediaEntry.4	INTEGER	R/O	△
ipRoutingDiscards	ip.23	Counter	R/O	○
ipForward	ip.24	Aggregate	-	○

12. ETHERNET CONTROL

MIB	OID	SYNTAX	ACCESS	SUPPORT
ipForwardNumber	ipForward .1	Gauge	R/O	o
ipForwardTable	ipForward .2	Aggregate	-	o
ipForwardDest	ipForwardTable.1	IpAddress	R/O	o
ipForwardMask	ipForwardTable.1	IpAddress	R/O	o
ipForwardPolicy	ipForwardTable.1	INTEGER	R/O	x
ipForwardNextHop	ipForwardTable.1	IpAddress	R/O	o
ipForwardIfIndex	ipForwardTable.1	INTEGER	R/O	o
ipForwardType	ipForwardTable.1	INTEGER	R/O	x
ipForwardProto	ipForwardTable.1	INTEGER	R/O	x
ipForwardAge	ipForwardTable.1	INTEGER	R/O	x
ipForwardInfo	ipForwardTable.1	ObjectID	R/O	x
ipForwardNextHopAS	ipForwardTable.1	INTEGER	R/O	x
ipForwardMetric1	ipForwardTable.1	INTEGER	R/O	x
ipForwardMetric2	ipForwardTable.1	INTEGER	R/O	x
ipForwardMetric3	ipForwardTable.1	INTEGER	R/O	x
ipForwardMetric4	ipForwardTable.1	INTEGER	R/O	x
ipForwardMetric5	ipForwardTable.1	INTEGER	R/O	x

Table 12-8 icmp group

MIB	OID	SYNTAX	ACCESS	SUPPORT
icmpInMsgs	icmp.1	Counter	R/O	o
icmpInErrors	icmp.2	Counter	R/O	o
icmpInDestUnreachs	icmp.3	Counter	R/O	o
icmpInTimeExcds	icmp.4	Counter	R/O	o
icmpInParmProbs	icmp.5	Counter	R/O	o
icmpInSrcQuenchs	icmp.6	Counter	R/O	o
icmpInRedirects	icmp.7	Counter	R/O	o
icmpInEchos	icmp.8	Counter	R/O	o
icmpInEchoReps	icmp.9	Counter	R/O	o
icmpInTimestamps	icmp.10	Counter	R/O	o
icmpInTimestampReps	icmp.11	Counter	R/O	o
icmpInAddrMasks	icmp.12	Counter	R/O	o
icmpInAddrMaskReps	icmp.13	Counter	R/O	o
icmpOutMsgs	icmp.14	Counter	R/O	o
icmpOutErrors	icmp.15	Counter	R/O	o
icmpOutDestUnreachs	icmp.16	Counter	R/O	o
icmpOutTimeExcds	icmp.17	Counter	R/O	o
icmpOutParmProbs	icmp.18	Counter	R/O	o
icmpOutSrcQuenchs	icmp.19	Counter	R/O	o
icmpOutRedirects	icmp.20	Counter	R/O	o
icmpOutEchos	icmp.21	Counter	R/O	o
icmpOutEchoReps	icmp.22	Counter	R/O	o
icmpOutTimestamps	icmp.23	Counter	R/O	o
icmpOutTimestampReps	icmp.24	Counter	R/O	o
icmpOutAddrMasks	icmp.25	Counter	R/O	o

12. ETHERNET CONTROL

MIB	OID	SYNTAX	ACCESS	SUPPORT
icmpOutAddrMaskReps	icmp.26	Counter	R/O	○

Table 12-9 tcp group

MIB	OID	SYNTAX	ACCESS	SUPPORT
tcpRtoAlgorithm	tcp.1	INTEGER	R/O	○
tcpRtoMin	tcp.2	INTEGER	R/O	○
tcpRtoMax	tcp.3	INTEGER	R/O	○
tcpMaxConn	tcp.4	INTEGER	R/O	○
tcpActiveOpens	tcp.5	Counter	R/O	○
tcpPassiveOpens	tcp.6	Counter	R/O	○
tcpAttemptFails	tcp.7	Counter	R/O	○
tcpEstabResets	tcp.8	Counter	R/O	○
tcpCurrEstab	tcp.9	Gauge	R/O	○
tcpInSegs	tcp.10	Counter	R/O	○
tcpOutSegs	tcp.11	Counter	R/O	○
tcpRetransSegs	tcp.12	Counter	R/O	○
tcpConnTable	tcp.13	Aggregate	-	○
tcpConnEntry	tcpConnTable.1	Aggregate	-	○
tcpConnState	tcpConnEntry.1	INTEGER	R/O	△
tcpConnLocalAddress	tcpConnEntry.2	IpAddress	R/O	○
tcpConnLocalPort	tcpConnEntry.3	INTEGER	R/O	○
tcpConnRemAddress	tcpConnEntry.4	IpAddress	R/O	○
tcpConnRemPort	tcpConnEntry.5	INTEGER	R/O	○
tcpInErrs	tcp.14	Counter	R/O	○
tcpOutRsts	tcp.15	Counter	R/O	○

Table 12-10 udp group

MIB	OID	SYNTAX	ACCESS	SUPPORT
udpInDatagrams	udp.1	Counter	R/O	○
udpNoPorts	udp.2	Counter	R/O	○
udpInErrors	udp.3	Counter	R/O	○
udpOutDatagrams	udp.4	Counter	R/O	○
udpTable	udp.5	Aggregate	-	○
udpEntry	udpTable.1	Aggregate	-	○
udpLocalAddress	udpEntry.1	IpAddress	R/O	○
udpLocalPort	udpEntry.2	INTEGER	R/O	○

Table 12-11 snmp group

MIB	OID	SYNTAX	ACCESS	SUPPORT
snmpInPkts	snmp.1	Counter	R/O	○
snmpOutPkts	snmp.2	Counter	R/O	○
snmpInBadVersions	snmp.3	Counter	R/O	○
snmpInBadCommunityNames	snmp.4	Counter	R/O	○
snmpInBadCommunityUses	snmp.5	Counter	R/O	○

12. ETHERNET CONTROL

MIB	OID	SYNTAX	ACCESS	SUPPORT
snmpInASNParseErrs	snmp.6	Counter	R/O	o
snmpInTooBig	snmp.8	Counter	R/O	o
snmpInNoSuchNames	snmp.9	Counter	R/O	o
snmpInBadValues	snmp.10	Counter	R/O	o
snmpInReadOnly	snmp.11	Counter	R/O	o
snmpInGenErrs	snmp.12	Counter	R/O	o
snmpInTotalReqVars	snmp.13	Counter	R/O	o
snmpInTotalSetVars	snmp.14	Counter	R/O	o
snmpInGetRequests	snmp.15	Counter	R/O	o
snmpInGetNexts	snmp.16	Counter	R/O	o
snmpInSetRequests	snmp.17	Counter	R/O	o
snmpInGetResponses	snmp.18	Counter	R/O	o
snmpInTraps	snmp.19	Counter	R/O	o
snmpOutTooBig	snmp.20	Counter	R/O	o
snmpOutNoSuchNames	snmp.21	Counter	R/O	o
snmpOutBadValues	snmp.22	Counter	R/O	o
snmpOutGenErrs	snmp.24	Counter	R/O	o
snmpOutGetRequests	snmp.25	Counter	R/O	o
snmpOutGetNexts	snmp.26	Counter	R/O	o
snmpOutSetRequests	snmp.27	Counter	R/O	o
snmpOutGetResponses	snmp.28	Counter	R/O	o
snmpOutTraps	snmp.29	Counter	R/O	o
snmpEnableAuthenTraps	snmp.30	IpAddress	R/W	o

12.2.4 Enterprise MIB

- **Enterprise Number**

The Enterprise Number of LEADER ELECTRONICS CORP. is 20111.
iso(1).org(3).dod(6).internet(1).private(4).enterprises(1).leader(20111)

- **Enterprise MIB File**

Obtain the enterprise MIB file using your PC Web browser.

Connect the LV 5838 to your PC, open a Web browser, and enter “http://IP address assigned to the LV 5838” in the address bar. The following web browsers have been confirmed to work.

- Internet Explorer Ver.8.0
- Mozilla Firefox Ver.15.0
- Google Chrome Ver.21.0




Figure 12-3 Entering the IP address

When the following page appears, right-click “DOWNLOAD,” and click “Save Link As.” Check that the extension is “.my.” If it is set to any other extension, specify “.my.”




Figure 12-4 Saving the enterprise MIB file

- **Enterprise MIB Structure**

The enterprise MIB structure is shown below.

```

leader OBJECT IDENTIFIER ::= { enterprises 20111 }
lv5838 OBJECT IDENTIFIER ::= { leader 25 }
lv5838ST1 OBJECT IDENTIFIER ::= { lv5838 1 }
I25panelTBL OBJECT IDENTIFIER ::= { lv5838ST1 1 }    <-- Panel key
I25assignTBL OBJECT IDENTIFIER ::= { lv5838ST1 2 }    <-- Assign menu
I25modeTBL OBJECT IDENTIFIER ::= { lv5838ST1 3 }      <-- Mode menu
I25sysTBL OBJECT IDENTIFIER ::= { lv5838ST1 4 }       <-- System menu
I25trapTBL OBJECT IDENTIFIER ::= { lv5838ST1 5 }      <-- Trap information

```

- **ACCESS**

In the tables, "ACCESS" indicates the following:

	Indication	Description
ACCESS	R/W	Information that can be read and written from the SNMP managers.

Table 12-12 I25panelTBL(1) group

MIB	OID	SYNTAX	ACCESS	VALUE/RANGE
I25plInput	I25panelTBL.1	INTEGER	R/W	1 = a 2 = b
I25plAes	I25panelTBL.2	INTEGER	R/W	1 = sdi 2 = ext
I25plWin	I25panelTBL.3	INTEGER	R/W	1 = win1 2 = win2
I25plMulti	I25panelTBL.4	INTEGER	R/W	1 = single 2 = multi
I25plLoudness	I25panelTBL.5	INTEGER	R/W	1 = start 2 = pause

Table 12-13 I25assignTBL(2) group

MIB	OID	SYNTAX	ACCESS	VALUE/RANGE
I25assignModeGroup1	I25assignTBL.1	INTEGER	R/W	2 = mono 3 = stereo 4 = 5.1 5 = 5.1_dm 6 = custom
I25assignModeGroup2	I25assignTBL.2	INTEGER	R/W	1 = off 2 = mono 3 = stereo 4 = 5.1 5 = 5.1_dm 6 = custom
I25assignPhonesL	I25assignTBL.3	INTEGER	R/W	1 = ch1 (Omitted) 16 = ch16 17 = dolby1 (Omitted) 24 = dolby8 25 = dolby_aux
I25assignPhonesR	I25assignTBL.4	INTEGER	R/W	1 = ch1 (Omitted) 16 = ch16 17 = dolby1 (Omitted) 24 = dolby8 25 = dolby_aux

12. ETHERNET CONTROL

MIB	OID	SYNTAX	ACCESS	VALUE/RANGE
I25assignAuxCh	I25assignTBL.5	INTEGER	R/W	1 = lt_rt 2 = lo_ro 3 = mono 4 = mute
I25assignAuxChDrc	I25assignTBL.6	INTEGER	R/W	1 = line 2 = rf
I25assignGroup1TBL	I25assignTBL.7	Aggregate	-	-
I25assignGroup1L	I25assignGroup1TBL.1	INTEGER	R/W	1 = ch1 (Omitted) 16 = ch16 17 = non_connect
I25assignGroup1R	I25assignGroup1TBL.2	INTEGER	R/W	1 = ch1 (Omitted) 16 = ch16 17 = non_connect
I25assignGroup1C	I25assignGroup1TBL.3	INTEGER	R/W	1 = ch1 (Omitted) 16 = ch16 17 = non_connect
I25assignGroup1Lfe	I25assignGroup1TBL.4	INTEGER	R/W	1 = ch1 (Omitted) 16 = ch16 17 = non_connect
I25assignGroup1Ls	I25assignGroup1TBL.5	INTEGER	R/W	1 = ch1 (Omitted) 16 = ch16 17 = non_connect
I25assignGroup1Rs	I25assignGroup1TBL.6	INTEGER	R/W	1 = ch1 (Omitted) 16 = ch16 17 = non_connect
I25assignGroup2TBL	I25assignTBL.8	Aggregate	-	-
I25assignGroup2L	I25assignGroup2TBL.1	INTEGER	R/W	1 = ch1 (Omitted) 16 = ch16 17 = non_connect
I25assignGroup2R	I25assignGroup2TBL.2	INTEGER	R/W	1 = ch1 (Omitted) 16 = ch16 17 = non_connect
I25assignGroup2C	I25assignGroup2TBL.3	INTEGER	R/W	1 = ch1 (Omitted) 16 = ch16 17 = non_connect
I25assignGroup2Lfe	I25assignGroup2TBL.4	INTEGER	R/W	1 = ch1 (Omitted)

12. ETHERNET CONTROL

MIB	OID	SYNTAX	ACCESS	VALUE/RANGE
				16 = ch16 17 = non_connect
I25assignGroup2Ls	I25assignGroup2TBL.5	INTEGER	R/W	1 = ch1 (Omitted) 16 = ch16 17 = non_connect
I25assignGroup2Rs	I25assignGroup2TBL.6	INTEGER	R/W	1 = ch1 (Omitted) 16 = ch16 17 = non_connect

Table 12-14 I25modeTBL(3) group

MIB	OID	SYNTAX	ACCESS	VALUE/RANGE
I25modeDisplay	I25modeTBL.1	INTEGER	R/W	1 = meter 2 = lissajou 3 = surround 4 = loudness 5 = status
I25modeMeterTBL	I25modeTBL.2	Aggregate	-	-
I25modeMeterResponse	I25modeMeterTBL.1	INTEGER	R/W	1 = truepeak 2 = ppm1 3 = ppm2 4 = vu
I25modeMeterPeakHold	I25modeMeterTBL.2	INTEGER	R/W	1 = off 2 = truepeak 3 = ppm1 4 = ppm2
I25modeMeterPeakHold_time	I25modeMeterTBL.3	INTEGER	R/W	1 = 0.0 2 = 0.5 3 = 1.0 4 = 2.0 5 = 3.0 6 = 4.0 7 = 5.0 8 = hold
I25modeMeterScaleMag	I25modeMeterTBL.4	INTEGER	R/W	1 = off 2 = on
I25modeMeterGroup	I25modeMeterTBL.5	INTEGER	R/W	1 = group1 2 = group2 3 = all 4 = 1-8 5 = 9-16
I25modeLissaTBL	I25modeTBL.3	Aggregate	-	-
I25modeLissaMono	I25modeLissaTBL.1	INTEGER	R/W	1 = ch1 (Omitted) 16 = ch16

12. ETHERNET CONTROL

MIB	OID	SYNTAX	ACCESS	VALUE/RANGE
I25modeLissaL	I25modeLissaTBL.2	INTEGER	R/W	1 = ch1 (Omitted) 16 = ch16
I25modeLissaR	I25modeLissaTBL.3	INTEGER	R/W	1 = ch1 (Omitted) 16 = ch16
I25modeLissaAutoGain	I25modeLissaTBL.4	INTEGER	R/W	1 = on 2 = off
I25modeLissaGroup	I25modeLissaTBL.5	INTEGER	R/W	1 = group1 2 = group2 3 = all 4 = 1-8 5 = 9-16
I25modeSurrTBL	I25modeTBL.4	Aggregate	-	-
I25modeSurrDisplay	I25modeSurrTBL.1	INTEGER	R/W	1 = both 2 = lissajou 3 = surround
I25modeSurrMode	I25modeSurrTBL.2	INTEGER	R/W	1 = normal 2 = phantom
I25modeSurrAutoGain	I25modeSurrTBL.3	INTEGER	R/W	1 = on 2 = off
I25modeSurrGroup	I25modeSurrTBL.4	INTEGER	R/W	1 = group1 2 = group2
I25modeLoudTBL	I25modeTBL.5	Aggregate	-	-
I25modeLoudDisplay	I25modeLoudTBL.1	INTEGER	R/W	1 = chart 2 = bar 3 = num 4 = meter 5 = num_only
I25modeLoudScale	I25modeLoudTBL.2	INTEGER	R/W	1 = off 2 = 1min 3 = 4min 4 = 10min 5 = 30min 6 = 1hour 7 = 2hour 8 = 4hour 9 = 6hour 10 = 12hour 11 = 24hour
I25modeLoudScaleChart	I25modeLoudTBL.3	INTEGER	R/W	2 = 1min 3 = 4min 4 = 10min 5 = 30min 6 = 1hour 7 = 2hour

12. ETHERNET CONTROL

MIB	OID	SYNTAX	ACCESS	VALUE/RANGE
				8 = 4hour 9 = 6hour 10 = 12hour 11 = 24hour
I25modeLoudStyle	I25modeLoudTBL.4	INTEGER	R/W	1 = vert 2 = hori
I25modeLoudScaleMagBar	I25modeLoudTBL.5	INTEGER	R/W	1 = off 2 = wide 3 = narrow
I25modeLoudScaleMagMeter	I25modeLoudTBL.6	INTEGER	R/W	2 = wide 3 = narrow
I25modeLoudGroup	I25modeLoudTBL.7	INTEGER	R/W	1 = group1 2 = group2
I25modeLoudSelect	I25modeLoudTBL.8	INTEGER	R/W	1 = momentary 2 = shortterm 3 = integrated 4 = all
I25modeStatusTBL	I25modeTBL.6	Aggregate	-	-
I25modeStatusMode	I25modeStatusTBL.1	INTEGER	R/W	1 = aud_sec 2 = sdi-sec 3 = eventlog 4 = phy 6 = loud_log
I25modeStatusDisplay	I25modeStatusTBL.2	INTEGER	R/W	1 = aud_status 2 = ch_status 3 = userbit 4 = dolby_meta 5 = dolby_ebi
I25modeStatusScale	I25modeStatusTBL.3	INTEGER	R/W	1 = 50ms 2 = 100ms 3 = 500ms 4 = 1.0s 5 = 2.5s
I25modeStatusSource	I25modeStatusTBL.4	INTEGER	R/W	1 = aeesebu 2 = sdi_anc
I25modeStatusChStatusTBL	I25modeStatusTBL.5	Aggregate	-	-
I25modeStatusChStatusCh	I25modeStatusChStatusTBL.1	STRING	R/W	1 to 16
I25modeStatusChStatusAlign	I25modeStatusChStatusTBL.2	INTEGER	R/W	1 = lsb 2 = msb
I25modeStatusUsrBitTBL	I25modeStatusTBL.6	Aggregate	-	-
I25modeStatusUserBitCh	I25modeStatusUserBitTBL.1	STRING	R/W	1 to 16
I25modeStatusUserBitAlign	I25modeStatusUserBitTBL.2	INTEGER	R/W	1 = lsb 2 = msb
I25modeStatusEventlog	I25modeStatusTBL.7	INTEGER	R/W	1 = stop 2 = start
I25modeStatusPhySource	I25modeStatusTBL.8	INTEGER	R/W	1 = ch1/2

12. ETHERNET CONTROL

MIB	OID	SYNTAX	ACCESS	VALUE/RANGE
				2 = ch3/4 3 = ch5/6 4 = ch7/8 5 = ch9/10 6 = ch11/12 7 = ch13/14 8 = ch15/16 9 = ext-sync
I25modeStatusMetaProgram	I25modeStatusTBL.9	INTEGER	R/W	1 = prm1 2 = prm2 3 = prm3 4 = prm4 5 = prm5 6 = prm6 7 = prm7 8 = prm8
I25modeStatusEbiProgram	I25modeStatusTBL.10	INTEGER	R/W	1 = prm1 2 = prm2 3 = prm3 4 = prm4 5 = prm5 6 = prm6 7 = prm7 8 = prm8

Table 12-15 I25sysTBL(4) group

MIB	OID	SYNTAX	ACCESS	VALUE/RANGE
I25sysExternalTBL	I25sysTBL.1	Aggregate	-	-
I25sysExternalSdi	I25sysExternalTBL.1	INTEGER	R/W	1 = input 2 = output
I25sysExternalAes	I25sysExternalTBL.2	INTEGER	R/W	1 = input 2 = output
I25sysTimecode	I25sysTBL.2	INTEGER	R/W	1 = off 2 = ltc 3 = vitc 4 = d_vitc 5 = aesebu 6 = ltc_ext
I25sysSrcTBL	I25sysTBL.3	Aggregate	-	-
I25sysSrcFlag	I25sysSrcTBL.1	INTEGER	R/W	1 = on 2 = off
I25sysSrcCh	I25sysSrcTBL.2	INTEGER	R/W	1 = ch1_2 2 = ch3_4 3 = ch5_6 4 = ch7_8 5 = ch9_10

12. ETHERNET CONTROL

MIB	OID	SYNTAX	ACCESS	VALUE/RANGE
				6 = ch11_12 7 = ch13_14 8 = ch15_16 9 = internal
I25sysExtref	I25sysTBL.4	INTEGER	R/W	1 = video_sync 2 = wordclock 3 = cw
I25sysExtrefClock	I25sysTBL.5	INTEGER	R/W	1 = 48khz 2 = 44.1khz 3 = 32khz
I25sysExtrefTermination	I25sysTBL.6	STRING	R/W	1 = 75 2 = 20k
I25sysLogMode	I25sysTBL.7	INTEGER	R/W	1 = overwrite 2 = stop
I25sysSettingWarning	I25sysTBL.8	STRING	R/W	-40 to 0
I25sysSettingRefrence	I25sysTBL.9	STRING	R/W	-40 to 0
I25sysScale	I25sysTBL.10	INTEGER	R/W	1 = dbfs 2 = nordic 3 = din4 = bbc
I25sysLoudTBL	I25sysTBL.11	Aggregate	-	-
I25sysLoudMeasure	I25sysLoudTBL.1	INTEGER	R/W	1 = bs1770-2 2 = arib 3 = ebu 4 = atsc 5 = custom
I25sysLoudTargetLevel	I25sysLoudTBL.2	STRING	R/W	-99 to 0
I25sysLoudLfeGain	I25sysLoudTBL.3	STRING	R/W	0 to 10 (in steps of 0.5)
I25sysLoudBlockSize	I25sysLoudTBL.4	STRING	R/W	200 to 30000 (in steps of 50)
I25sysLoudOverlapSize	I25sysLoudTBL.5	STRING	R/W	0 to 99
I25sysLoudAbsolute	I25sysLoudTBL.6	INTEGER	R/W	1 = on 2 = off
I25sysLoudAbsoluteLevel	I25sysLoudTBL.7	STRING	R/W	-99 to 0
I25sysLoudRelative	I25sysLoudTBL.8	INTEGER	R/W	1 = on 2 = off
I25sysLoudRelativeLevel	I25sysLoudTBL.9	STRING	R/W	-99 to 0
I25sysLoudShorttermAverage	I25sysLoudTBL.10	STRING	R/W	200 to 30000 (in steps of 50)
I25sysLoudMomentaryAverage	I25sysLoudTBL.11	STRING	R/W	100 to 1000 (in steps of 25)
I25sysLoudRangeAverage (to be supported in the future)	I25sysLoudTBL.12	STRING	R/W	200 to 30000 (in steps of 50)
I25sysLoudRangeOverlap (to be supported in the future)	I25sysLoudTBL.13	STRING	R/W	0 to 99

12. ETHERNET CONTROL

MIB	OID	SYNTAX	ACCESS	VALUE/RANGE
I25sysLoudMarkOver	I25sysLoudTBL.14	INTEGER	R/W	1 = on 2 = off
I25sysLoudMarkRelative	I25sysLoudTBL.15	INTEGER	R/W	1 = on 2 = off
I25sysErrorTBL	I25sysTBL.12	Aggregate	-	-
I25sysErrorOver	I25sysErrorTBL.1	INTEGER	R/W	1 = on 2 = off
I25sysErrorOverLevel	I25sysErrorTBL.2	STRING	R/W	0 to 99
I25sysErrorClip	I25sysErrorTBL.3	INTEGER	R/W	1 = on 2 = off
I25sysErrorClipDuration	I25sysErrorTBL.4	STRING	R/W	1 to 100
I25sysErrorMute	I25sysErrorTBL.5	INTEGER	R/W	1 = on 2 = off
I25sysErrorMuteDuration	I25sysErrorTBL.6	STRING	R/W	1 to 100 (in steps of 10)
I25sysErrorMuteLevel	I25sysErrorTBL.7	STRING	R/W	-99 to -60
I25sysErrorSilent	I25sysErrorTBL.8	INTEGER	R/W	1 = on 2 = off
I25sysErrorSilentDuration	I25sysErrorTBL.9	STRING	R/W	1 to 5000 (in steps of 10)
I25sysErrorFrame (to be supported in the future)	I25sysErrorTBL.10	INTEGER	R/W	1 = on 2 = off
I25sysErrorFrameGuardband (to be supported in the future)	I25sysErrorTBL.11	INTEGER	R/W	1 = rdd6 2 = custom
I25sysErrorFrameSdMin (to be supported in the future)	I25sysErrorTBL.12	STRING	R/W	8 to 30
I25sysErrorFrameSdMax (to be supported in the future)	I25sysErrorTBL.13	STRING	R/W	8 to 30
I25sysErrorFrameHdMin (to be supported in the future)	I25sysErrorTBL.14	STRING	R/W	8 to 30
I25sysErrorFrameHdMax (to be supported in the future)	I25sysErrorTBL.15	STRING	R/W	8 to 30
I25sysErrorParity	I25sysErrorTBL.16	INTEGER	R/W	1 = on 2 = off
I25sysErrorValiildity	I25sysErrorTBL.17	INTEGER	R/W	1 = on 2 = off
I25sysErrorCrc	I25sysErrorTBL.18	INTEGER	R/W	1 = on 2 = off
I25sysErrorDolbyCrc	I25sysErrorTBL.19	INTEGER	R/W	1 = on 2 = off
I25sysErrorAudioBch	I25sysErrorTBL.20	INTEGER	R/W	1 = on 2 = off
I25sysErrorAudioParity	I25sysErrorTBL.21	INTEGER	R/W	1 = on 2 = off
I25sysErrorAudioDbn	I25sysErrorTBL.22	INTEGER	R/W	1 = on

12. ETHERNET CONTROL

MIB	OID	SYNTAX	ACCESS	VALUE/RANGE
				2 = off
I25sysErrorAudioInhibit	I25sysErrorTBL.23	INTEGER	R/W	1 = on 2 = off
I25sysErrorAudioSample	I25sysErrorTBL.24	INTEGER	R/W	1 = on 2 = off
I25sysDolbyTBL	I25sysTBL.13	Aggregate	-	-
I25sysDolbyModule	I25sysDolbyTBL.1	INTEGER	R/W	1 = off 2 = dolby-e 3 = dolby-digital 4 = dolby-digital-plus
I25sysDolbyInput	I25sysDolbyTBL.2	INTEGER	R/W	1 = ch1_2 2 = ch3_4 3 = ch5_6 4 = ch7_8 5 = ch9_10 6 = ch11_12 7 = ch13_14 8 = ch15_16
I25sysDolbyE_Dialonorm	I25sysDolbyTBL.3	INTEGER	R/W	1 = off 2 = on
I25sysDolbyE_Pulldown	I25sysDolbyTBL.4	INTEGER	R/W	1 = off 2 = on
I25sysDolbyDigitalListening	I25sysDolbyTBL.5	INTEGER	R/W	1 = full 2 = ex 3 = 3stereo 4 = phantom 5 = stereo 6 = mono
I25sysDolbyDigitalPrologic	I25sysDolbyTBL.6	INTEGER	R/W	1 = off 2 = on
I25sysDolbyDigitalDrc	I25sysDolbyTBL.7	INTEGER	R/W	1 = bypass 2 = line 3 = rf

Table 12-16 I25trapTBL(5) group

MIB	OID	SYNTAX	ACCESS	VALUE/RANGE
I25trapStrTBL	I25trapTBL.1	Aggregate	-	- (Variable BindingList)
I25trapIpTBL	I25trapTBL.2	Aggregate	-	-
I25trapIp1TBL	I25trapIpTBL 1	Aggregate	-	-
I25trapManagerIp1	I25trapIp1TBL 1	IpAddress	R/W	Trap transmission destination manager IP address 1
I25trapManagerIp1Act	I25trapIp1TBL 2	IpAddress	R/W	1 = disable 2 = enable
I25trapIp2TBL	I25trapIpTBL 2	Aggregate	-	-

12. ETHERNET CONTROL

MIB	OID	SYNTAX	ACCESS	VALUE/RANGE
I25trapManagerIp2	I25trapIp2TBL 1	IpAddress	R/W	Trap transmission destination manager IP address 2
I25trapManagerIp2Act	I25trapIp2TBL 2	IpAddress	R/W	1 = disable 2 = enable
I25trapIp3TBL	I25trapIpTBL 3	Aggregate	-	-
I25trapManagerIp3	I25trapIp3TBL 1	IpAddress	R/W	Trap transmission destination manager IP address 3
I25trapManagerIp3Act	I25trapIp3TBL 2	IpAddress	R/W	1 = disable 2 = enable
I25trapIp4TBL	I25trapIpTBL 4	Aggregate	-	-
I25trapManagerIp4	I25trapIp4TBL 1	IpAddress	R/W	Trap transmission destination manager IP address 4
I25trapManagerIp4Act	I25trapIp4TBL 2	IpAddress	R/W	1 = disable 2 = enable

12.2.5 Extended TRAP (Variable Binding List)

● **index 1**

OID: leader(20111).lv5838(25).lv5838ST1(1).trapTBL(5).trapStrTBL(1).1.0
 Syntax: Counter
 Range: 1 to 4294967295 (overflow occurs if this range is exceeded)
 Description: The total number of enterprise traps sent after starting up

● **index 2**

OID: leader(20111).lv5838(25).lv5838ST1(1).trapTBL(5).trapStrTBL(1).2.0
 Syntax: Octet String
 Range: Up to 40 characters
 Description: Date and time of error occurrence and line information
 YYYY/MM/DD hh:mm:ss input channel (A/B)
 Example: 2012/05/01 10:08:59 A

● **index 3**

OID: leader(20111).lv5838(25).lv5838ST1(1).trapTBL(5).trapStrTBL(1).3.0
 Syntax: Octet String
 Range: Up to 40 characters
 Description: Format information
 Example: 1080sF/30

● **index 4**

OID: leader(20111).lv5838(25).lv5838ST1(1).trapTBL(5).trapStrTBL(1).4.0
 Syntax: Octet String
 Range: Up to 40 characters
 Description: Error information (see the table below)
 Example: BCH_ERR

Table 12-17 Error information

Specific Trap Type	Indication	Description
1	FAN_STOP	Fan stop detection
2	NO_SIGNAL	No signal
3	UNKNOWN	Format error detection
4	None	No error (at error recovery)
10	BCH_ERR	(SDI) BCH error detection
11	PRTY_ERR	(SDI) Parity error detection
12	DBN_ERR	(SDI) DBN error detection
13	INH_ERR	(SDI) Inhibit error detection
14	SAMPLE_ERR	(SDI) Sample Number error detection
20	AUD_OVER_ERR	(AUDIO) LevelOver error detection
21	AUD_CLIP_ERR	(AUDIO) Clip error detection
22	AUD_MUTE_ERR	(AUDIO) Mute error detection
23	AUD_SILENT_ERR	(AUDIO) Silence error detection
24	AUD_PARITY_ERR	(AUDIO) Parity error detection
25	AUD_CRC_ERR	(AUDIO) CRC error detection
26	AUD_VALIDITY_ERR	(AUDIO) Validity error detection

12.3 Time Server Function

You can configure the LV 5838 so that it periodically connects to a time server on the network and queries the time.

12.3.1 Procedure

1. Configure the Ethernet settings on the ETHER&REMOTE tab.

Set Time Server to ON. Set the ETHERNET SETTING IP Address, TIME SERVER SETTING IP Address, and Time Zone. For details on Time Zone, see the next section. [Reference] See section 5.2, “Configuring the Ethernet and Remote Settings.”

SYSTEM → F•1 SYSTEM SETUP → F•3 NEXT TAB →

GENERAL	ETHER&REMOTE	ETC				
ETHERNET SETTING						
Ethernet	<input type="checkbox"/> DHCP <input checked="" type="checkbox"/> IP					
IP Address	<table border="1"><tr><td>192</td><td>168</td><td>0</td><td>1</td></tr></table>	192	168	0	1	MAC ADDRESS
192	168	0	1			
Subnet Mask	<table border="1"><tr><td>255</td><td>255</td><td>255</td><td>0</td></tr></table>	255	255	255	0	00:00:00:00:00:00
255	255	255	0			
Gateway	<table border="1"><tr><td>0</td><td>0</td><td>0</td><td>0</td></tr></table>	0	0	0	0	
0	0	0	0			
TIME SERVER SETTING						
Time Server	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF	Time Zone				
IP Address	<table border="1"><tr><td>192</td><td>168</td><td>0</td><td>2</td></tr></table>	192	168	0	2	+09:00
192	168	0	2			
SNMP SETTING						
SNMP	<input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF					
ACCESS	<input checked="" type="checkbox"/> RO <input type="checkbox"/> RW					
SNMP Trap	<input checked="" type="checkbox"/> OFF <input type="checkbox"/> ON					
REMOTE SETTING						
Alarm Polarity	<input checked="" type="checkbox"/> Positive <input type="checkbox"/> Negative					
Select	<input checked="" type="checkbox"/> Recall <input type="checkbox"/> Recall and 5838_02 <input type="checkbox"/> 5838_01+02					

Figure 12-5 ETHER&REMOTE tab

2. Press F•1 COMPLETE.

3. Restart the LV 5838.

If you didn't make any changes, you do not have to restart.

4. Connect the Ethernet port on the rear panel to the network.


Use a UTP cable (category 5).

The LV 5838 connects to the NTP server at the following times.

- When you press F•1 COMPLETE in SYSTEM SETUP
- Once every approximately 10 minutes

When the LV 5838 connects normally to a time server, the date and time are displayed at the upper left of the screen.

Otherwise, “SNTP:ERR” appears in the top row, and the time that was set up to that point appears in the bottom row.



12.3.2 Time Adjustment Value

The date and time information exchanged with a time server is Coordinated Universal Time (UTC). Therefore, the time must be adjusted in accordance with the country or region where the device is used in. On the ETHER&REMOTE tab, set Time Zone to one of the following values.

Table 12-18 Time adjustment values

Country or region	Time Zone
Baker Island, Howland Island	-12:00
American Samoa, Niue	-11:00
Hawaii, Western part of Aleutian Islands	-10:00
French Polynesia, Marquesas Islands	-09:30
Alaska	-09:00
United States, Canada, Mexico (Pacific Time Zone)	-08:00
United States, Canada, Mexico (Mountain Time Zone)	-07:00
United States, Canada, Mexico (Central Time Zone)	-06:00
United States, Canada (Eastern Time Zone), Cuba, Peru	-05:00
Venezuela	-04:30
Canada (Atlantic Time Zone), most of Lesser Antilles, Brazil (Amazon Time), Chile	-04:00
Canada (Newfoundland)	-03:30
Brazil (Brazilian Time), Argentina, Greenland	-03:00
Brazil (Fernando de Noronha)	-02:00
Azores, Cape Verde	-01:00
United Kingdom, Ireland, Portugal, Iceland, Morocco (East Africa), Ghana, etc.	00:00
Central European Time (France, Germany, etc.), West Africa Time (Nigeria, Congo, etc.)	+01:00
Eastern European Time (Finland, Greece, etc.), Central Africa Time, South Africa	+02:00
Russia (Kaliningrad Oblast), Ukraine, Belarus, Saudi Arabia, Eastern Africa Time	+03:00
Iran	+03:30
Russia (Moscow), Azerbaijan, Georgia, United Arab Emirates, Mauritius	+04:00
Afghanistan	+04:30
Pakistan	+05:00
India	+05:30
Nepal	+05:45
Russia (Yekaterinburg), Kazakhstan, Bangladesh	+06:00
Myanmar, Cocos Islands	+06:30
Russia (Omsk), Mongolia, Thailand, Vietnam, Djakarta	+07:00
Russia (Krasnoyarsk), China, Mongolia, Malaysia, Australia (Western Australia)	+08:00
Australia (Eucla)	+08:45
Russia (Irkutsk), Korea, Japan, Palau	+09:00
Australia (Northern Territory, South Australia)	+09:30
Russia (Yakutsk), Guam, Eastern Australia Time	+10:00
Australia (Lord Howe)	+10:30
Russia (Vladivostok), Solomon Islands, New Caledonia	+11:00
Russia (Magadan), New Zealand, Fiji, Kiribati (Gilbert Islands)	+12:00
New Zealand (Chatham Islands)	+12:45
Tonga, Kiribati (Phoenix Islands), Samoa	+13:00

12. ETHERNET CONTROL


Country or region	Time Zone
Kiribati (Line Islands), Tokelau	+14:00

13. REFERENCE MATERIAL


13.1 Menu Tree

The menus that are displayed vary depending on the LV 5838 settings and whether a USB memory device is connected to the LV 5838.


13.1.1 Mode Menu




13. REFERENCE MATERIAL



13.1.2 System Menu



13.1.3 Assign Menu



13.2 Firmware Update History

This manual was written for firmware version 2.1.

You can view the firmware version by pressing **F•6** SYSTEM INFO on the system menu.

- **Ver. 2.1**

- The Dolby option is now supported.

- **Ver. 2.0**

- A feature that displays clip, mute, and silence errors has been added.

- **Ver. 1.7**

- On the PHY status display, a feature that displays physical sampling frequencies has been added.

- **Ver. 1.5**

- On the loudness display, a display mode that shows only the measured values with large characters have been added.
- On the loudness display, a feature that overwrites a portion of the measured results and recalculates the entire data has been added.
- On the loudness display, a feature that indicates true peaks that exceed the threshold has been added. (5.1 DM will be supported in the future.)
- On the loudness display, a display for recording true peaks that exceed the threshold to the log has been added.
- On the loudness display, a feature that indicates relative gating that is less than or equal to the threshold has been added.
- On the loudness display, a feature that records loudness data sequentially to a USB memory device has been added.
- On the loudness display, the duration of the log when only one input is used has been expanded to 24 hours (12 hours for two inputs).

- **Ver. 1.3**

- The meter on the loudness display now displays a larger green target level range for easier viewing.

- **Ver. 1.2**

- LTC INPUT is now supported.
- Real time has been added as one of the loudness display measurement triggers.

Following information is for Chinese RoHS only

所含有毒有害物质信息

部件号码: LV 5837/LV 5838



此标志适用于在中国销售的电子信息产品, 依据2006年2月28日公布的《电子信息产品污染控制管理办法》以及SJ/T11364-2006《电子信息产品污染控制标识要求》, 表示该产品在使用完结后可再利用。数字表示的是环境保护使用期限, 只要遵守与本产品有关的安全和使用上的注意事项, 从制造日算起在数字所表示的年限内, 产品不会产生环境污染和对人体、财产的影响。产品适当使用后报废的方法请遵从电子信息产品的回收、再利用相关法令。详细请咨询各级政府主管部门。

产品中有毒有害物质或元素的名称及含量

部件名称 Parts	有毒有害物质或元素 Hazardous Substances in each Part					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
实装基板	×	○	○	○	○	○
主体部	×	○	○	○	○	○
液晶显示模组	○	○	○	○	○	○
风扇	×	○	○	○	○	○
外筐	○	○	○	○	○	○
线材料一套	×	○	○	○	○	○
附件	○	○	○	○	○	○
包装材	○	○	○	○	○	○
电池	○	○	○	○	○	○

备注)

- : 表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T11363-2006 规定的限量要求以下。
- ×: 表示该有毒有害物质或元素至少在该部件的某一均质材料中的含量超出SJ/T11363-2006 标准规定的限量要求。

LEADER

LEADER ELECTRONICS CORP.

2-6-33 Tsunashima-Higashi, Kohoku-ku, Yokohama 223-8505, Japan

PHONE:81-45-541-2123 FAX:81-45-541-2823 <http://www.leader.co.jp>