

Leader

LV5333 Software Upgrade Procedure

Caution: Please DO NOT turn off the power during software is upgraded.

1. Unzip the **xxxx.zip** file.
2. Copy the **LV5333_UPDATE** folder to a USB memory drive.
NOTE: USB Memory Drive maximum capacity to use is 4GB and it should be formatted as FAT32.
3. Insert the USB memory drive to the LV5333.
4. Power on the unit and it will display the update menu.
5. Press **[F1]** to update. It takes around 5 minutes for the update process.
6. END