# VIDEO

# **LEADER**

The LT 444 is a changeover unit that switches to the backup system when accidents occur.



## • GENERAL

The LT 444 is a changeover unit that automatically switches the signal from the primary signal to the backup signal when problems are detected in the primary signal. Two systems of input signals (primary and backup) are connected to the LT 444, and the LT 444 detects errors on the amplitude of the primary input signal.

A single LT 444 provides 11 channels. HD-SDI (channels 1 to 6 only), SD-SDI, AES/EBU digital audio, analog black burst signal, and tri-level sync signals are supported through the configuration of the internal switch.

If a switch occurs from the primary signal to the backup signal, the LT 444 indicates the channel that caused the problem on the panel LED.

The LT 444 can be configured in the system with the LT 443D.

### • FEATURES

### Input/Output

Provides 11 channels (a single channel consists of PRIMARY input, BACKUP input, and OUTPUT output) on a single LT 444.

- Delay for Starting the Monitor The delay for starting the error monitor at power up can be set to FAST or SLOW depending on the rise time of the system signal source being connected.
- Determination Criteria of the Signal Level The internal preset switch allows level detection switching among SD-SDI, AES/EBU digital audio, NTSC or PAL analog black burst, HD analog trilevel sync, HD-SDI (only supported on channels 1 to 6), and other signals.

# Error Display

When a signal level error is detected, the LT 444 illuminates the error LED on the panel as well as the panel LED that indicates the channel causing the problem. This feature allows quick investigation of the problem.

### LT 444 REAR PANEL



# **LEADER**



### • SPECIFICATIONS

LT 444

Inputs	
PRIMARY inputs:	1 input each for 11 channels
•	$(75 \Omega BNC connector)$
BACKUP input:	1 input each for 11 channels
	(75 $\Omega$ BNC connector)
Outputs	( ,
OUTPUT outputs :	1 output each for 11 channels
•	(75 $\Omega$ BNC connector)
nput/Output Characteristics (CH1 to CH11)	
Return Loss:	30 dB 0 to 10 MHz
	15 dB 10 MHz to 750 MHz
	10 dB 750 MHz to 1.5 GHz
Insertion Loss:	0.2 dB 0 to 10 MHz
	0.5 dB 10 MHz to 200 MHz
	2.0 dB 200 MHz to 1.5 GHz
Cross Talk:	-60 dB 0 to 10 MHz
	-30 dB 10 MHz to 1.0 GHz
	-20 dB 1.0 GHz to 1.5 GHz

#### **Delay for Starting the Monitor**

Select from two delay settings for starting the error monitor at power up according to the rise time of the system signal source connected to the LT 444. FAST: 1 minute or more (60 to 80 s)

1	minute or more (60 to 80 s)
4	minutes or more (240 to 320 s)

#### Input Signal Type

SLOW:

Set the type of input signal applied to the LT 444 using the internal dip switch. Signal Type: HD-SDI (CH1 to CH6 only)

HD-SDI (CH1 to CH6 only) SD-SDI (270 Mb/s) SD-SDI (143 Mb/s) AES/EBU digital audio Tri-level sync signal NTSC black burst PAL black burst

#### **Determination Criteria of the Signal Level**

Detection Level:

#### Detects an error when the amplitude of the input signal drops by 2 to 5 dB from the defined level and makes the switch. The detection level varies slightly depending on the type of signal specified using the internal dip switch.

The detection level can be set to LOW or HIGH for each signal type.

#### **Detection Reference Level**

\*1The signals levels inside the parentheses are those during normal conditions.

# When the Determination Criteria is Set to Low HD-SDI

(CH1 to CH6 only):	450 to 635 mV (800 mV)
SD-SDI (270 Mb/s):	450 to 635 mV (800 mV)
SD-SDI (143 Mb/s):	450 to 635 mV (800 mV)
AES/EBU audio:	631 to 794 mV (1000 mV)
NTSC black burst:	-180 to -227 mV (-286 mV)
PAL black burst:	-190 to -238 mV (-300 mV)
Tri-level sync:	337 to 476 mV (600 mV)

When the Determination Criteria is Set to HIGH		
HD-SDI (CH1 to CH6 only): SD-SDI (270 Mb/s): SD-SDI (143 Mb/s): AES/EBU audio: NTSC black burst: PAL black burst: Tri-level sync:	505 to 713 mV (800 mV) 505 to 713 mV (800 mV) 505 to 713 mV (800 mV) 734 to 924 mV (1000 mV) -210 to -264 mV (-286 mV) -220 to -277 mV (-300 mV) 379 to 535 mV (600 mV)	
User-Defined Detectio USER setting 1: USER setting 2: Expansion of the Dete	n Level Setting (CH7 to CH11 only) Set between -100 mV to -700 mV *2 Set between -100 mV to -700 mV *2 setion Level Using the Attenuator (CH7	
Set the internal attenua	tor to expand the detection level further by	
USER setting 1: USER setting 2: *2When a signal equivant The specifications of depending on the wa	Set between -700 mV to -3500 mV *2 Set between -700 mV to -3500 mV *2 alent to the H.SYNC waveform is applied. f the detection level may not be achieved veform shape.	
Error Display Total Error LED:	Notifies errors by illuminating the error	
Error Channel LED:	Detects the channel causing the error and notifies the channel by illuminating the corresponding LED.	
Panel Key Lock Time to Key Lock:	The key lock is automatically enabled when key operation is not detected for 60 s.	
External Control (REMO Application: Inputs:	TE) Connector For external remote control. RESET, AUTO SWITCHING, and TOGGLE SYNC FAULT and SYNC SOURCE	
Connector Type:	9-pin Dsub connector	
Environmental Condition Operating Temperature: Operating Humidity: Operating Environment: Operating Altitude: Overvoltage Category: Pollution Degree:	ns 0 to 45 °C ≤90 % RH (without condensation) Indoor use Up to 2,000 m II 2	
Power Requirements:	90 to 250 VAC (no switching necessary), 50/60 Hz 25 Wmax.	
Dimensions and Weight:	426 (W) x 44 (H) x 560 (D) mm (excluding protrusions), 4 kg	
Accessories:	Rack supports 2   Rack support attachment screws 4   Power cord 1	

Instruction manual ..... 1