

VIDEO CHANGEOVER

The LT 444 is a changeover unit that switches to the backup system when accidents occur.

CE
Upon request

RoHS



LT 444 CHANGEOVER

GENERAL

The LT 444 is a changeover unit that automatically switches the signal from the primary signal to the backup signal when problems are detected in the primary signal. Two systems of input signals (primary and backup) are connected to the LT 444, and the LT 444 detects errors on the amplitude of the primary input signal.

A single LT 444 provides 11 channels. HD-SDI (channels 1 to 6 only), SD-SDI, AES/EBU digital audio, analog black burst signal, and tri-level sync signals are supported through the configuration of the internal switch.

If a switch occurs from the primary signal to the backup signal, the LT 444 indicates the channel that caused the problem on the LED front panel.

The LT 444 can be configured in the system with the LT 443D.

FEATURES

■ Input/Output

Provides 11 channels (a single channel consists of PRIMARY input, BACKUP input, and OUTPUT output) on a single LT 444.

■ Delay for Starting the Monitor

The delay for starting the error monitor at power up can be set to FAST or SLOW depending on the rise time of the system signal source being connected.

■ Determination Criteria of the Signal Level

The internal preset switch allows level detection switching among SD-SDI, AES/EBU digital audio, NTSC or PAL analog black burst, HD analog tri-level sync, HD-SDI (only supported on channels 1 to 6), and other signals.

■ Error Display

When a signal level error is detected, the LT 444 illuminates the error LED on the panel as well as the LED panel that indicates the channel causing the problem. This feature allows quick investigation of the problem.

The LT 444 can be configured in the system with the LT443D



SPECIFICATIONS

LT 444

Inputs	
PRIMARY inputs:	1 input each for 11 channels (75 Ω BNC connector)
BACKUP input:	1 input each for 11 channels (75 Ω BNC connector)
Outputs	
OUTPUT outputs :	1 output each for 11 channels (75 Ω BNC connector)
Input/Output Characteristics (CH1 to CH11)	
Return Loss:	30 dB 0 to 10 MHz 15 dB 10 to 750 MHz 10 dB 750 MHz to 1.5 GHz
Insertion Loss:	0.2 dB 0 to 10 MHz 0.5 dB 10 to 200 MHz 2.0 dB 200 MHz to 1.5 GHz
Cross Talk:	-60 dB 0 to 10 MHz -30 dB 10 MHz to 1.0 GHz -20 dB 1.0 GHz to 1.5 GHz
Delay for Starting the Monitor	
Select from two delay settings for starting the error monitor at power up according to the rise time of the system signal source connected to the LT 444.	
FAST:	1 minute or more (60 to 80 s)
SLOW:	4 minutes or more (240 to 320 s)
Input Signal Type	
Set the type of input signal applied to the LT 444 using the internal dip switch.	
Signal Type:	HD-SDI (CH1 to CH6 only) SD-SDI (270 Mb/s) SD-SDI (143 Mb/s) AES/EBU digital audio Tri-level sync signal NTSC black burst PAL black burst
Determination Criteria of the Signal Level	
Detection Level:	Detects an error when the amplitude of the input signal drops by 2 to 5 dB from the defined level and makes the switch. The detection level varies slightly depending on the type of signal specified using the internal dip switch. The detection level can be set to LOW or HIGH for each signal type.
Detection Reference Level	
*1The signals levels inside the parentheses are those during normal conditions.	
When the Determination Criteria is Set to Low	
HD-SDI	
(CH1 to CH6 only):	450 to 635 mV (800 mV)
SD-SDI (270 Mb/s):	450 to 635 mV (800 mV)
SD-SDI (143 Mb/s):	450 to 635 mV (800 mV)
AES/EBU audio:	631 to 794 mV (1000 mV)
NTSC black burst:	-180 to -227 mV (-286 mV)
PAL black burst:	-190 to -238 mV (-300 mV)
Tri-level sync:	337 to 476 mV (600 mV)

When the Determination Criteria is Set to HIGH	
HD-SDI	
(CH1 to CH6 only):	505 to 713 mV (800 mV)
SD-SDI (270 Mb/s):	505 to 713 mV (800 mV)
SD-SDI (143 Mb/s):	505 to 713 mV (800 mV)
AES/EBU audio:	734 to 924 mV (1000 mV)
NTSC black burst:	-210 to -264 mV (-286 mV)
PAL black burst:	-220 to -277 mV (-300 mV)
Tri-level sync:	379 to 535 mV (600 mV)
User-Defined Detection Level Setting (CH7 to CH11 only)	
USER setting 1:	Set between -100 to -700 mV *2
USER setting 2:	Set between -100 to -700 mV *2
Expansion of the Detection Level Using the Attenuator (CH7 to CH11 only)	
Set the internal attenuator to expand the detection level further by 5 times	
USER setting 1:	Set between -700 to -3500 mV *2
USER setting 2:	Set between -700 to -3500 mV *2
*2 When a signal equivalent to the H.SYNC waveform is applied. The specifications of the detection level may not be achieved depending on the waveform shape.	
Error Display	
Total Error LED:	Notifies errors by illuminating the error LED on the panel.
Error Channel LED:	Detects the channel causing the error and notifies the channel by illuminating the corresponding LED.
Panel Key Lock	
Time to Key Lock:	The key lock is automatically enabled when key operation is not detected for 60 s.
External Control (REMOTE) Connector	
Application:	For external remote control.
Inputs:	RESET, AUTO SWITCHING, and TOGGLE SYNC
Outputs:	FAULT and SYNC SOURCE
Connector Type:	9-pin Dsub connector
Environmental Conditions	
Operating Temperature:	0 to 45 °C
Operating Humidity:	≤90 % RH (without condensation)
Operating Environment:	Indoor use
Operating Altitude:	Up to 2,000 m
Overtoltage Category:	II
Pollution Degree:	2
Power Requirements	
90 to 250 VAC (no switching necessary), 50/60 Hz, 25 Wmax.	
Dimensions and Weight	
426 (W) x 44 (H) x 560 (D) mm (excluding protrusions), 4 kg	
Accessories	
Rack supports	2
Rack support attachment screws	4
Power cord	1
Instruction manual	1

LT 444 REAR PANEL

